



**Model GSP30B**



Model #: \_\_\_\_\_

Serial #: \_\_\_\_\_



## Instruction Manual for Globe Label Printing Scale Model GSP30B

### For Service on Your Scale

1. Visit our website at ***www.globefoodequip.com***
2. Or call the Globe Service Department at 937-299-8625 and ask for contact information for your local service company.

### **- IMPORTANT SAFETY NOTICE -**

This manual contains important safety instructions which must be strictly followed when using this equipment.


Visit our website for information on additional products available from Globe.

***www.globefoodequip.com***

***Slicers, Mixers, Countertop Cooking Equipment, Meat Choppers & Scales***

WARRANTY REGISTRATION  
SCAN THE QR CODE WITH YOUR MOBILE DEVICE OR GO TO  
WWW.GLOBEFOODEQUIP.COM  
TO FILL OUT AND SUBMIT YOUR WARRANTY REGISTRATION.

WWW.GLOBEFOODEQUIP.COM/SUPPORT/WARRANTY-REGISTRATION-FORM





# Index

IMPORTANT NOTICE .....	5
SAFETY TIPS.....	5
INSTALLATION .....	6
KEY SCALE COMPONENTS.....	6
LOADING/UNLOADING LABELS .....	7-8
INITIAL SCALE SET UP	
Changing Current Date And Time.....	8
Entering Shop Name And Address.....	9
PLU (Price Look Up) SET UP	
Setting Up PLUs.....	10-11
Deleting A PLU .....	11
PRESET KEY SET UP	
Setting Up Preset Keys .....	12
Setting Up Cassette Preset Keys .....	12
Setting Up Tare Preset Function Keys.....	13
Setting Up Preset Function Keys.....	14
Deleting Preset Keys .....	14
CASSETTE SET UP FOR STANDARD (E11) LABELS .....	15
CASSETTE SET UP FOR SAFE HANDLING (E12) LABELS.....	16
CASSETTE SET UP FOR INGREDIENT (E13) LABELS.....	17
OPERATING INSTRUCTIONS (PLU'S)	
Manual Label Print.....	19
Automatic Label Print (Weighed Items).....	19
Automatic Label Print (Fixed Priced Items) .....	19
Using Function Keys.....	20-21
CLEANING/MAINTENANCE .....	22
TROUBLESHOOTING .....	23
TARE WEIGHT .....	24
USB SCALE BACKUP AND RESTORE	
Scale To USB .....	25
USB To Scale .....	25-26
ADDITIONAL FEATURES .....	26
WARRANTY .....	28



**GLOBE FOOD EQUIPMENT CO.**  
**2153 DRYDEN RD**  
**DAYTON, OH 45439**  
**TOLL FREE: 800-347-5423**  
**PHONE: 937-299-5493**  
**FAX: 937-299-4147**  
**E-MAIL: [info@globefoodequip.com](mailto:info@globefoodequip.com)**  
**WEBSITE: [www.globefoodequip.com](http://www.globefoodequip.com)**



## Important Notice

**YOU MUST CALL YOUR LOCAL WEIGHTS AND MEASURES OFFICE BEFORE YOU USE YOUR NEW SCALE. USUALLY WEIGHTS AND MEASURES IS A DEPARTMENT OF THE COUNTY AUDITOR'S OFFICE. THIS SCALE MUST BE CERTIFIED BEFORE IT CAN BE USED.**

**YOU RUN THE RISK OF BEING FINED IF THIS SCALE IS NOT CERTIFIED BY YOUR LOCAL WEIGHTS AND MEASURES.**

## Safety Tips

This manual contains a number of precautions to follow in order to help promote safe use of this equipment.

**Warnings affecting your personal safety are indicated by:**



**Warnings related to possible damage to the equipment are indicated by:**



To ensure safe operation, the general safety tips below must be followed.

- **DISCONNECT** the scale from the power source (unplug) before servicing or opening
- **ONLY** trained and qualified service personnel should attempt repairs
- **ONLY** use correct type and rating of fuses and parts
- **NEVER** immerse the scale in water or spray with hose
- **DO NOT** put the scale in a dishwasher

### **GROUNDING**



This machine is provided with a three prong grounding plug. The outlet to which this plug is connected must be properly grounded. If the receptacle is not the proper grounding type, contact an electrician. Do not, under any circumstances, cut or remove the third (ground prong) from the power cord or use any adapter plug (Figure 5-1 and Figure 5-2).



Figure 5-1 Correct



Figure 5-2 Incorrect

# Installation

Make sure the scale is placed on a stable, flat surface.

Avoid the following areas when installing the machine:



- Areas subject to high temperatures or high humidity
- Areas exposed to direct sunlight
- Areas where water or other liquids can be easily spilled on the machine
- Areas subject to excessive vibration or unstable surfaces
- Areas exposed to direct cold air
- Areas subject to low temperatures
- Areas subject to a lot of dirt
- Areas with large voltage fluctuations

Check the level indicator to make sure the scale is level. If the machine is not level, weighing may not be accurate.

To adjust the machine to a level position, rotate the four adjustment feet until the level bubble is completely centered in the round level indicator.

Plug the power cord into the AC power outlet on the bottom side of the scale.



## Key Scale Components




Operating Keysheet



Scale Set-Up Keysheet



# Loading/Unloading Labels



Use only Globe Food Labels. Damage to thermal head can occur. To order labels, contact a local Globe Representative or Globe Food Equipment.

**IMPORTANT:** Before installing a new roll of labels, remove 5 to 6 blank labels so only backing paper is fed through the printer.

## Loading Roll of Labels

1. Open the side cover.
2. Release the printer head by pushing the release lever down. See Figure 7-1.
3. Make sure the stopper lever of the roll holder is pulled down.
4. Load the label roll onto the roll holder.
5. Insert the label paper (with the label side up) under the guide.
6. Continue to pull the label paper through and make sure it is fed over the metal bar shown in Figure 7-2 and under the bar\*. See Figure 7-1.
7. Turn the winding bobbin counter clockwise so the slot is on the top. See Figure 7-3.
8. Insert the paper under the slot on the winding bobbin. See Figure 7-3.
9. Pull up on the stopper lever, then slide it inwards to secure the label roll.
10. Make sure the label paper is against the edge\*\*. See Figure 7-1.
11. Push down on the lock lever until the print head locks into position.
12. With the scale plugged in and turned on, press the Feed key on the keypad once or twice in order to securely turn the paper around the winding bobbin. Continue to press the Feed button until the labels are ejected from the printer.




Figure 7-2




Figure 7-3

**NOTE:** If you receive an error message (1011), it indicates that the label is not in the proper position. Press the CLR key then press the Feed key again to feed the labels through the printer. You may need to do this step a couple of times.

13. Close the side cover.



## Loading/Unloading Labels



Figure 8-1

### Unloading Remaining Label Roll

1. Open the side cover.
2. Release the printer head by pushing down on the release lever. See Figure 8-1.
3. Pull the winding bobbin lever outwards to loosen the paper wound around the winding bobbin; then remove the paper from the winding bobbin.
4. Pull the stopper lever of the roll holder to make it straight; then remove the label roll from the path and the roll holder.

## Initial Scale Set Up

### Changing Current Date And Time

**IMPORTANT:** Before using the scale for the first time, follow these steps to make sure that the current date and time is displayed.

1. Make sure the scale is plugged in, turned on and there is nothing on the weigh platter.

**NOTE:** The “Clock Check” screen will display. See Figure 8-2.

2. Press the Enter key on the keypad to proceed.
3. Key in 4000 and press the Mode key. The display will show: C00 ADJUST
4. Press the Enter key. Display will show : C01 DATE TIME
5. Key in 111111 and press the PLU key.
6. Press the Enter key. Display will show: C01-01 DATE and date displayed
7. Key in new date data.

Example: April 1, 2015

Key in 04012015

8. Press the Enter key. The date will be displayed as month, day and year. If date is correct, press the Enter key. If not correct, key in the new date and press the Enter key. Display will show: C01-02 TIME and time displayed



Figure 8-2



# Initial Scale Set Up

9. The time will be displayed as military time with time separators between the hour, minute and seconds. If the time is correct, press the Enter key. If not correct, key in the new time (hour, minute, seconds) and press the Enter key.
10. After the date and time have been entered, press the Mode key. Display will show 19001-000 ENT or CLR
11. Press the Mode key three times to return to normal operation.

**NOTE: To make sure that the date and time is correct, power off the scale and then power on the scale to view the "Clock Check" screen.**

## Entering Shop Name And Address (optional)

1. Make sure the scale is plugged in, turned on, and there is nothing on the weigh platter.
2. Key in 9000 and press the Mode key. The display will show: P00 PROGRAM
3. Key in 5 and press the ENTER key. Display will show: P06 STORE
4. Key in 11111 and press the PLU key. Display will show: P06 STORE
5. Press the Enter key. Display will show: P06-00 NO. 0000 >No<
6. Press the Enter key. Display will show P06-01 NAME >ED
7. Press the Edit key. Display will show 13001-0000 ENT or CLR.
8. Press the Enter key. Display will show INP 0001-0000-00  
See Figure 9-1.
9. Use the Scale Set-Up keysheet to key in the store name (48 character maximum).




Figure 9-1

**NOTE: Only one character of the store name will display at a time. Use the right arrow key on the Scale Set-Up keysheet to cycle through the letters of the store name.**

**NOTE: To enter one of the symbols (not a letter), select the symbol key. If the symbol needed is on the top of the symbol key, select the shift key then the appropriate symbol key.**

**NOTE: To delete a character that is not needed, press the Back Space key or arrow keys and Char Delete key.**

10. After the store name has been entered, press the Mode key. Display will show 19001-0000 ENT or CLR
- NOTE: Press Enter to save or CLR to cancel.**
11. Press the Enter key. Display will show: P06-00 NO. 0001 >No<
12. Press the down arrow on the Scale Set-Up keysheet two times. Display will show: P06-02 ADDRESS >ED
13. Press the Edit key. Display will show INP 0001-0000-00
14. Use the Scale Set-Up keysheet to key in the store address (this includes the street address, city, state, and zip) (48 character maximum).
- NOTE: To enter one of the symbols (not a letter), select the symbol key. If the symbol needed is on the top of the symbol key, select the shift key then the appropriate symbol key.**
15. After the store name has been entered, press the Mode key. Display will show 19001-0000 ENT or CLR
- NOTE: Press Enter to save or CLR to cancel.**
16. Press the Mode key three times to return to normal operation.

# PLU (Price Look-up) Set Up

## Setting Up PLUs

1. Make sure the scale is plugged in, turned on and there is nothing on the platter.
2. Key in 9000 and press the Mode key. Display will show: P00 PROGRAM
3. Press the Enter key. Display will show: P01 PLU
4. Key in 111111 and press the PLU key.
5. Press the Enter key. Display will show: P01-00 PLU >No<
6. Key in the PLU number (5 digit maximum) and press the PLU key. Display will show: 13001-0000 ENT OR CLR.

**NOTE: Press the Enter key to accept the PLU number or the CLR key to cancel. CLR will return you to the PLU number entry screen and Enter will move forward to the top of the PLU entry menu.**

7. Display will show: P01-01 <SALE1>
8. Press the Edit key. See Figure 10-1. Display will show: INP 0001-0000 00
9. Use the Scale Set-Up Keysheet to key in the PLU name (24 character maximum per line, 2 line maximum, e.g. GROUND BEEF, BANANAS). See Figure 10-2.
10. Enter the first line of data. If you only want one line of data, then press the Enter key. If you want a second line of data, press the New Line key. Enter the second line of data, and press the Enter key to complete. See Figure 10-3. Display will show: P01-01 <SALE1>
11. Press the Enter key. Display will show: P01-01-01 SALES 0
12. Key in 0 if the PLU is a weighing price item. Key in 1 if the PLU is a fixed price item.



Figure 10-1




Figure 10-2

- NOTE: For weighing price items, proceed to step 13. For fixed price items, proceed to step 18.**
13. Press the Enter key. Display will show: P01-01-04 PRICE 0.00
  14. Key in the unit price (5 digit maximum do NOT include decimal) and press the Enter key.
  15. Press the Enter key again. Display will show: P01-01-10 TARE 0.000
  16. Key in the tare weight (4 digit maximum/2 digit minimum - tare weight is a three place decimal that must end in 0 or 5) or 0 if none and press the Enter key two times. Display will show: P01-01-12 P TARE 0.0

**NOTE: For a detailed explanation of tares, refer to the Tare Weight section.**

17. Key in the tare percentage (3 digit maximum) or 0 if none and press the Enter key.

**NOTE: For weighing price items, proceed to step 26.**

18. Press the Enter key. Display will show: P01-01-04 PRICE 0.00
19. Key in the unit price (5 digit maximum) and press the Enter key.
20. Press the Enter key again. Display will show: P01-01-06 QTY 0
21. Key in quantity. Press the Enter key.
22. Press the Enter key again. Display will show: P01-01-07 UNIT TYPE 0
23. Key in unit type. Press the Enter key.
24. Press the Enter key again. Display will show: P01-01-09 FIX WGT 0
25. Key in fixed weight. Press the Enter key.




Figure 10-3

## PLU (Price Look-up) Set Up

26. Press the Enter key again. Display will show: P01-01 <SALE1>
27. Use the right arrow key on the Scale Set-Up Keysheet to select the date. Display will show: P01-06 <DATE>
28. Press the Enter key. Display will show: P01-06-01 P/D PRN 2  
**NOTE: Select 1 for package date to appear on label or 2 to remove package date from label.**
29. Key in 1 and press the Enter key.
30. Press the Enter key again. Display will show P01-06-04 SB DATE PRN 1  
**NOTE: Select 1 for sell by date to appear on label or 2 to remove sell by date from label.**
31. Key in 1 and press the Enter key.
32. Press the Enter key again. Display will show: P01-06-07 SHELF LF 1
33. Key in the number of days to expire (3 digit maximum) and press the Enter key.  
**NOTE: This will be used if the sell by date is printed on the label.**
34. Press the Enter key. Display will show: P01-06 <DATE>
35. Use the right arrow key on the Scale Set-Up Keysheet to select the code. Display will show P01-07 <CODE>
36. Press the Enter key. Display will show: P01-07-01 CODE 00000000  
**NOTE: The barcode can be the PLU number, which the scale defaults to, or the POS (point of sale) number. If the PLU number is to be in the barcode simply press the Enter key. If the POS number is to be in the barcode, key in the POS number (5 digit maximum) and press the Enter key. The scale can be reprogrammed to accept a 6 digit PLU or POS number. Contact Globe's Technical Service Department for assistance.**
37. Press the Mode key. Display will show: 19001-0000 ENT OR CLR.  
**NOTE: Press the Enter key to save or the CLR key to cancel.**
38. Press the Mode key. Display will show: P01 PLU
39. Repeat steps 3 through 37 to enter additional PLU numbers. When complete, press the Mode key twice to return to normal operation.

### Deleting A PLU

1. Make sure the scale is plugged in, turned on and there is nothing on the platter.
2. Key in 9000 and press the Mode key. The display will show: P00 PROGRAM
3. Key in 1 and press the Enter key. Display will show: P01 PLU
4. Key in 111111 and press the PLU key.
5. Press the Enter key. Display will show: P01-00 PLU >No.<
6. Press the down arrow key two times. Display will show: P01-00 No. 1 >PL  
**NOTE: Use the down arrow to select the PLU number to delete.**
7. Press the →0← Zero key. Display will show: 13002-0000 ENT OR CLR.  
**NOTE: Press the Enter key to save or the CLR key to cancel.**
8. Press the Enter key.
9. Press the Mode key three times to return to normal operation.

# Preset Key Set Up

## Setting Up PLU Preset Keys

1. Make sure the scale is plugged in, turned on and there is nothing on the weigh platter.
2. Key in 9000 and press the Mode key. Display will show: P00 PROGRAM
3. Key in 4 and press the Enter key. Display will show: P04 PRESET KEY
4. Key in 11111 and press the PLU key. Display will show: P04 PRESET KEY
5. Press the Enter key. Display will show: P04-01 000 0 000
6. Press the desired preset key. See Figure 12-1.




Figure 12-1

**NOTE:** Make sure to mark the selected preset key with the PLU name on the Operating Keysheet. See Figure 12-2.

**NOTE:** Two values can be stored on each preset key. The Lower Level preset function key is used to switch between upper and lower level. Refer to Operating Instructions (Function Keys).

7. Key in 1 for the preset function key flag number and press the Enter key.
8. Key in PLU number and press the desired preset key. See Figure 12-3.
9. Repeat step 5 through 8 to set up additional keys. When completed, press the Mode key three times to return to normal operation.

**NOTE:** In normal operation, use the Lower Level preset function key to switch between upper and lower level.




Figure 12-2

## Setting Up Cassette Preset Functions Keys

**NOTE:** Up to seven cassette's can be programed. Each cassette contains the label spec and label format for a label. Once you have setup the cassettes, you can change your label format by selecting the applicable cassette preset key.

1. Make sure the scale is plugged in, turned on and there is nothing on the weigh platter.
2. Key in 9000 and press the Mode key. Display will show: P00 PROGRAM
3. Key in 4 and press the Enter key. Display will show: P04 PRESET KEY
4. Key in 11111 and press the PLU key.
5. Press the Enter key. Display will show: P04-01 000 0 000
6. Press the desired preset key. See Figure 12-4.

**NOTE:** Make sure to mark the selected preset key with the PLU name on the Operating Keysheet. See Figure 12-2.

7. Key in 435 for the preset function key flag number and press the Enter key. Display will show: P04-01 435 74 0
8. Key in Cassette number. Press the desired preset key. See Figure 12-5.
9. Press the Mode key three times to return to normal operation.




Figure 12-3




Figure 12-4




Figure 12-5

# Preset Key Set Up

## Setting Up Tare Preset Functions Keys

1. Make sure the scale is plugged in, turned on and there is nothing on the weigh platter.
2. Key in 9000 and press the Mode key. Display will show: P00 PROGRAM
3. Key in 4 and press the Enter key. Display will show: P04 PRESET KEY
4. Key in 111111 and press the PLU key. Display will show: P04 PRESET KEY
5. Press the Enter key. Display will show: P04-01 000 0 000
6. Press the desired preset key. See Figure 13-1.

**NOTE:** Make sure to mark the selected preset key with the PLU name on the Operating Keysheet. See Figure 13-2.

**NOTE:** Two values can be stored on each preset key. The Lower Level preset function key is used to switch between upper and lower level. Refer to Operating Instructions (Function Keys).

7. Key in 2 for the preset function key flag number and press the Enter key. Display will show: P04-01 002 "1" 0
8. Key in weight of the container. Press the desired preset key. See Figure 13-3.

**NOTE:** Weight of the container must be entered in 3 or more decimal places. Example, if the weight of the container is 0.5 pounds, enter 500 with no decimal places. If the weight of the container is 1.5 pounds enter 1500 with no decimal places.

9. Press the Mode key three times to return to normal operation.



Figure 13-1




Figure 13-2




Figure 13-3

# Preset Key Set Up

## Setting Up Preset Function Keys

1. Make sure the scale is plugged in, turned on, and there is nothing on the weigh platter.
2. Key in 9000 and press the Mode key. The display will show: P00 PROGRAM
3. Key in 4 and press the Enter key. Display will show: P04 PRESET KEY
4. Key in 11111 and press the PLU key. Display will show: P04 PRESET KEY
5. Press the Enter key. Display will show: P04-01 000 0 000
6. Place the Operating Keysheet over the Scale Set-Up Keysheet. Press the desired preset key. Remove the Operating Keysheet and note which preset key was used.
7. Key in the desired preset function key flag number (see list below), press the Enter key.
8. Key in 0 (Warning: Press the number 0, below number 1, NOT the →0←Zero key.) and then press the preset key again to recognize the entry as the function key. Refer to Operating Instructions (Function Keys).

**NOTE: Display will not change. To make sure that the preset key is set, select any other key on the scale set-up keysheet and then the desired preset key again. Display should show the selected key with the preset function key flag just keyed in.**

**NOTE: Two values can be stored on each preset key. The Lower Level preset function key is used to switch between upper and lower level.**

### Preset function key flag

PLU	1
Auto Manu	75
U/P (Unit Price)	32
Lower Level	156
Cassette Switching	435
Tare	2
Fixed Price	3
X (Multiply)	4
Special Price	5
-\$ Price Discount	6
-% Percentage Discount	7
Save	8

9. Repeat steps 6 and 8 to set up additional keys. When completed press the Mode key three times to return to normal operation.

## Deleting Preset Keys

**IMPORTANT: This procedure will delete ALL preset keys at once!**

1. Make sure the scale is plugged in, turned on and there is nothing on the weigh platter.
2. Key in 9000 and press the Mode key. Display will show: P00 PROGRAM
3. Key in 4 and press the Enter key. Display will show: P04 PRESET KEY
4. Key in 11111 and press the PLU key. Display will show: P04 PRESET KEY
5. Press the Enter key.
6. Press the →0← Zero key. Display will show 14033-0000 ENT OR CLR  
**Note: Press the Enter key to execute or the CLR key to stop.**
7. There will be a long beep which signals that all preset keys have been deleted.
8. Press the Mode key three times to return to normal operation.



# Cassette Set Up for Standard (E11) Labels

Use Cassette's to select different label sizes. After a Cassette preset function key has been assigned, follow the steps below to program the label spec and label format for each cassette.

Before the Standard (E11) labels can be used, the scale needs to be set up for the new label size.

1. Load the labels. Refer to Loading/Unloading Labels.
2. Make sure nothing is on the weigh platter.
3. Select the desired Cassette preset function key.

**NOTE: Scale will beep two times to indicate Cassette preset function key has been selected.**

4. Key in 6000 and press the Mode key. Display will show: B00 SETUP
5. Enter 951753 and press the PLU key.
6. Key in 11 and press the Enter key. Display will show: B11 CASSETTE
7. Press the Enter key. The display will show: B11-01 CAST No. "01"

**NOTE: Up to seven cassettes can be programed. Each cassette contains the label spec and label format for a label.**

8. Press the down arrow key on the Scale Set-Up Keysheet three times. Display will show: B11-04 FMT No. "001"
9. Key in format number "001" and press the Enter key. Display will show: B11-04 FMT No. 001
10. Press the End key. Display will show: B11 CASSETTE
11. Press the down arrow key on the Scale Set-Up Keysheet one time. Display will show: B12 LABEL SPEC
12. Press the Enter key. Display will show: B12-01 LABEL No. "01"
13. Use the down arrow key on the Scale Set-Up Keysheet to select B12-12 LABEL GAP 2.0 mm

**NOTE: Label gap is the pitch between labels. Depending on the label, a small adjustment may need to be made.**

14. Press the down arrow key on the Scale Set-Up Keysheet one time. Display will show: B12-13 SENS DIST. "71.0mm"
15. Key in 710 (do NOT enter decimal point) and press the Enter key.
16. Press the End key. Display will show: B12 LABEL SPEC
17. Press the down arrow key one time. Display will show: B13 LABEL FORMAT
18. Press the Enter key. Display will show: B13-01 <BASIC>
19. Press the down arrow key on the Scale Set-Up Keysheet two times. Display will show: B13-01-02 WIDTH "560"
20. Key in 560 (do NOT enter decimal point) and press Enter key.
21. Press the Enter key again. Display will show: B13-01-03 HEIGHT "440"
22. Key in 440 (do NOT enter decimal point) and press the Enter key.
23. Press the Mode key three times to return to normal operation.

**NOTE: It may be necessary to print two or three labels in order for the alignment to appear correct on the label.**



# Cassette Set up for Safe Handling (E12) Labels

Use Cassette's to select different label sizes. After a Cassette preset function key has been assigned, follow the steps below to program the label spec and label format for each cassette.

Before the Safe Handling (E12) labels can be used, the scale needs to be set up for the new label size.

1. Load the labels. Refer to Loading/Unloading Labels.

2. Make sure nothing is on the weigh platter.

3. Select the desired Cassette preset function key.

**NOTE: Scale will beep two times to indicate Cassette preset function key has been selected.**

4. Key in 6000 and press the Mode key. Display will show: B00 SETUP

5. Enter 951753 and press the PLU key.

6. Key in 11 and press the Enter key. Display will show: B11 CASSETTE

7. Press the Enter key. Display will show: B11-01 CAST No. "01"

**NOTE: Up to seven cassettes can be programed. Each cassette contains the label spec and label format for a label.**

8. Press the down arrow key on the Scale Set-Up Keysheet three times. Display will show: B11-04 FMT No. "001"

9. Key in format number "002" and press the Enter key. Display will show: B11-04 FMT No. 002

10. Press the End key. Display will show: B11 CASSETTE

11. Press the down arrow key on the Scale Set-Up Keysheet one time. The display will show: B12 LABEL SPEC

12. Press the Enter key. Display will show: B12-01 LABEL No. "02"

13. Use the down arrow key to select B12-12 LABEL GAP 2.0 mm

**NOTE: Label gap is the pitch between labels. Depending on the label, a small adjustment may need to be made.**

14. Press the down arrow key on the Scale Set-Up Keysheet one time. Display will show: B12-13 SENS DIST. "71.0mm"

15. Key in 710 (do NOT enter decimal point) and press the Enter key.

16. Press the End key. Display will show: B12 LABEL SPEC

17. Press the down arrow key one time. The display will show: B13 LABEL FORMAT

18. Press the Enter key. Display will show: B13-01 <BASIC>

19. Press the down arrow key on the Scale Set-Up Keysheet two times. Display will show: B13-01-02 WIDTH "560"

20. Key in 560 (do NOT enter decimal point) and press Enter key.

21. Press the Enter key again. Display will show: B13-01-03 HEIGHT "440"

22. Key in 590 (do NOT enter decimal point) and press the Enter key.

23. Press the Mode key three times to return to normal operation.

**NOTE: It may be necessary to print two or three labels in order for the alignment to appear correct on the label.**

# Cassette Set up for Ingredient (E13) Labels

Use Cassette's to select different label sizes. After a Cassette preset function key has been assigned, follow the steps below to program the label spec and label format for each cassette.

**NOTE: Ingredient (E13) Labels can not be completed without the use of the ScaleLink Pro 5 Lite Maintenance Utility Software. Refer to the Scalelink Pro 5 lite Software User Guide for instructions on how to setup a ingredient label.**

Before the Ingredient (E13) labels can be used, the scale needs to be set up for the new label size.

1. Load the labels. Refer to Loading/Unloading Labels.
2. Make sure nothing is on the weigh platter.
3. Select the desired Cassette preset function key.

**NOTE: Scale will beep two times to indicate Cassette preset function key has been selected.**

4. Key in 6000 and press the Mode key. Display will show: B00 SETUP
5. Enter 951753 and press the PLU key.
6. Key in 11 and press the Enter key. Display will show: B11 CASSETTE
7. Press the Enter key. Display will show: B11-01 CAST No. "01"

**NOTE: Up to seven cassettes can be programed. Each cassette contains the label spec and label format for a label.**


8. Press the down arrow key on the Scale Set-Up Keysheet three times. Display will show: B11-04 FMT No. "001"
9. Key in format number "003" and press the Enter key. Display will show: B11-04 FMT No. 003
10. Press the End key. Display will show: B11 CASSETTE
11. Press the down arrow key on the Scale Set-Up Keysheet one time. Display will show: B12 LABEL SPEC
12. Press the Enter key. Display will show: B12-01 LABEL No. "03"
13. Use the down arrow key to select B12-12 LABEL GAP 2.0 mm

**NOTE: Label gap is the pitch between labels. Depending on the label, a small adjustment may need to be made.**

14. Press the down arrow key on the Scale Set-Up Keysheet one time. Display will show: B12-13 SENS DIST. "71.0mm"
15. Key in 710 (do NOT enter decimal point) and press the Enter key.
16. Press the End key. Display will show: B12 LABEL SPEC
17. Press the down arrow key one time. Display will show: B13 LABEL FORMAT
18. Press the Enter key. Display will show: B13-01 <BASIC>
19. Press the down arrow key on the Scale Set-Up Keysheet two times. Display will show: B13-01-02 WIDTH "560"
20. Key in 560 (do NOT enter decimal point) and press Enter key.
21. Press the Enter key again. Display will show: B13-01-03 HEIGHT "440"
22. Key in 800 (do NOT enter decimal point) and press the Enter key.
23. Press the Mode key three times to return to normal operation.

**NOTE: It may be necessary to print two or three labels in order for the alignment to appear correct on the label.**


# SAMPLES of all available labels for the GSP30B



**SAMPLE ONLY Standard GSP30B Label E11**



**SAMPLE ONLY Safe Handling GSP30B Label E12**



**SAMPLE ONLY Ingredient GSP30B Label E13**

# Operating Instructions (PLU's)

## Manual Label Print

1. Make sure the scale is plugged in, the weigh platter is on top of the scale, the scale is turned on.
2. Enter a PLU number and press the PLU key or press one of the PLU preset keys. The PLU information will be displayed.

**NOTE: To access the lower level of preset keys, press the Lower Level preset function key and then the preset key. Refer to Preset Key Set Up.**

3. If a tare weight was not programmed for the PLU and it is needed, do one of the following steps:
  - a. Place the empty container on the weigh platter and press the tare key or...
  - b. Enter the tare amount and press the tare key.

4. Place the product on the weigh platter and press the Print key for a label to print.

**NOTE: If the PLU is for a fixed priced item, press the Print key for the label. Product does not have to be placed on the platter.**

**NOTE: The scale will go back to 0.00.**

## Automatic Label Print (Weighed Items)

**NOTE: To print labels automatically when PLU is selected, you must first set-up the AUTO/MANU preset function key. Refer to Preset Key Set Up.**

1. Press the Auto Manu preset function key.

**NOTE: An arrow will show on the display pointing to the word AUTO. This indicates that the scale is in automatic label print mode.**

2. Enter a PLU number and press the PLU key or press one of the PLU preset keys. The PLU information will display.
3. If a tare weight was not programmed for the PLU and it is needed, do one of the following steps:
  - a. Place the empty container on the weigh platter and press the tare key or...
  - b. Enter the tare amount and press the tare key.
4. Place the product on the weigh platter and a label will automatically print.

**NOTE: While the scale is in the automatic label printing mode it will not reset to 0.00's. Continue to enter PLU numbers and weigh products.**

**NOTE: To stop automatic label print mode press the Auto Manu preset key. The arrow pointing to AUTO on the display will go out of view and the scale will reset to show all zeros.**

## Automatic Label Print (Fixed Priced Items)

**NOTE: To print labels automatically when PLU is selected, you must first set-up the AUTO/MANU preset function key. Refer to Preset Key Set-Up.**

1. Press the Auto Manu preset key.

**NOTE: An arrow will show on the display pointing to the word AUTO. This indicates that the scale is in automatic label print mode.**

2. Enter a PLU number and press the PLU key or press one of the preset keys. The PLU information will be displayed.
3. Enter the number of labels you want printed for this item and press the Print key. The number of labels entered will be printed automatically one after the other.

**NOTE: If you press the Print key without entering a number first, the scale will continue to automatically print labels until the Print key is pressed again.**

**NOTE: To stop automatic label print mode, press the Auto Manu preset key. The arrow pointing to AUTO on the display will go out of view. Press the Mode key to return to normal operation.**

# Operating Instructions (Function Keys)

## Using Function Keys

**NOTE:** Function keys must first be set up as preset keys. Refer to Preset Key Set Up.

**PLU** - Used to select a PLU preset function key.

1. Press the PLU preset function key.
2. Place the item to be weighed on the scale.
3. Press the Print key to issue a label.

**Auto Manu** - Used to print labels automatically.

**NOTE:** Make sure to change the Auto Manu preset key to MANUAL before selecting a fixed price, multiple, special price, -\$ price discount or -% percent discount preset function key. Labels will not print with the updated price if the scale is set to AUTO.

1. Key in the PLU and press the PLU key
2. Press the Auto Manu preset key. The auto indicator on the display will be lit.
3. Press the Auto Manu preset key. The auto indicator on the display will go off.
4. Press the Mode key to return to normal operation.

**Unit Price** - Used to print labels without the use of a PLU.

1. Place product on the scale.
2. Enter the unit price and press the Unit Price preset key.
3. Press the Print key two times.

**Lower Level Preset Keys** - Used to select lower level preset keys.

1. Press the Lower Level preset function key to select a PLU preset key or preset function key.
2. Press the PLU preset key or preset function key.

**NOTE:** The scale will return to the upper level preset keys after the product has been weighed and label has printed.

**Cassette Preset Keys** - Used to select label formats within a specified cassette.

1. Press the Cassette preset function key.

**NOTE:** Scale will beep two times to indicate Cassette preset key has been selected.

**Tare** - Used to find the weight of an empty container.

1. Key in the PLU and press the PLU key or press one of the PLU preset keys.
2. Press the Tare preset key.
3. Press the Print key to issue a label.

# Operating Instructions (Function Keys)

**Fixed Price** - Used to temporarily change the selling price for a fixed price item.

1. Key in the fixed priced PLU and press the PLU key or press one of the PLU preset keys.
2. Key in the temporary price.
3. Press the fixed price preset key.
4. Press the Print key to issue a label.

**Multiple** - Used to price multiple pieces of an item (fixed price items).

1. Key in the fixed priced PLU and press the PLU key or press one of the PLU preset keys.
2. Key in the quantity.

**NOTE: Maximum 99 pieces.**

3. Press the Multiple preset key.
4. Press the Print key to issue a label.

**Special Price** - Used to temporarily reduce the selling price.

1. Key in the PLU and press the PLU key or press one of the PLU preset keys.
2. If the PLU is a fixed price item, continue with step 3. If the PLU is a weighed item, place the product on the weigh platter so a total price is displayed.
3. Key in the special price.
4. Press the Special Price preset key.

**NOTE: The display will not change; however, when the label prints, it will show the special price.**

5. Press the Print key to issue a label.

**-\$ Price Discount** - Used to temporarily subtract an amount from the total price.

1. Key in the PLU and press the PLU key or press one of the PLU preset keys.
2. If the PLU is a fixed price item, continue with step 3. If the PLU is a weighed item, place the product on the receiving tray so a total price is displayed.
3. Key in the dollar amount to be discounted.
4. Press the -\$ Amount Discount preset key.

**NOTE: The display will not change; however, when the label prints, it will show the discounted price.**

5. Press the Print key to issue a label.

**-% Percent Discount** - Used to temporarily subtract a percentage from the total price.

1. Key in the PLU and press the PLU key or press one of the PLU preset keys.
2. If the PLU is a fixed price item, continue with step 3. If the PLU is a weighed item, place the product on the receiving tray so a total price is displayed.
3. Key in the percent amount to be discounted (3 digit maximum do NOT include decimal).
4. Press the % Percent Discount preset key.

**NOTE: The display will not change; however, when the label prints, it will show the discounted price.**

5. Press the Print key to issue a label.

**Save** - Used to maintain the called up PLU data.

1. Key in the PLU and press the PLU key or press one of the PLU preset keys.
2. Press the Save preset key. The save indicator on the display will be lit.
3. Press the Save preset key again to release the PLU data. The save indicator on the display will go off.
4. Press the Mode key to return to normal operation.


# Cleaning/Maintenance

## Cleaning

- Disconnect the power supply before cleaning.
- Keep the machine and Operator Keysheet free of dust and dirt.
- Make sure that all spills are wiped clean, especially on the weigh platter.
- Do not put components in dishwasher.
- Dilute detergent per supplier's instruction.
- Do not hose down or pressure wash any part of the scale.
- Never use a scrubber pad, steel wool, or abrasive material to clean the scale.
- Clean the scale with a mild detergent and warm water solution.
- Do not allow moisture to get into the load cell mounted under the scale weigh platter. Water damage is not covered under the limited warranty.
- When cleaning the scale, only use a soft, damp cloth with a mild cleaner. Never use volatile or caustic liquids.

## Cleaning the Print Head

1. Dip a cotton swab into the thermal print head cleaning solution provided with the scale. Isopropyl rubbing alcohol can also be used.
2. Rub the cotton swab on the print head until debris is removed.
3. Allow the alcohol to air dry.



Thermal Print Head



DO NOT use cloth or other material to dry the print head. This can possibly damage the print head.



If labels have become stuck to print head, **NEVER** use any sharp or metal object to scrape labels from print head. Doing so will damage the print head.

## Maintenance

It is recommended that the following steps be performed on a daily basis:

1. Make sure that there is a sufficient amount of labels remaining in the machine.
2. Clean the thermal head with a cotton swab, thermal head cleaning solution or isopropyl rubbing alcohol only.



# Troubleshooting

## **Scale will not light up.**

1. Check to make sure wall outlet has power to it.
2. Check and make sure power cord is plugged in.
3. Turn scale on by pushing the power switch on the left side of the scale.
4. Call for service.

## **Scale lights up but all functions are inoperable (locked up).**

1. Unplug scale from wall outlet, wait 10 seconds, plug scale back in. Turn the scale on by pushing the power switch on the left side of the scale.
2. Call for service.

## **Scale not weighing properly.**

1. Make sure scale weigh platter is mounted to scale properly.
2. Check to make sure nothing is touching weigh platter. If anything touches the platter it will affect the weight display.
3. Tare is improperly set.
4. Call for service.

## **Labels are automatically printing when an item is placed on the weigh platter.**

1. The machine is set in automatic mode. Press the AUTO MANU preset key to switch the scale back to manual mode. The AUTO indicator will go out of view.

## **Labels will not come out when print key is pushed.**

1. Make sure labels are properly installed. Refer to Loading/Unloading Labels.
2. Make sure labels have not stuck to print head area.



If labels have become stuck to print head, **NEVER** use any sharp or metal object to scrape labels from print head. Doing so will damage the print head. Refer to Cleaning/Maintenance.

## **Print on labels is not clear.**

1. Refer to Cleaning/Maintenance.

## **Error Messages**

**NOTE: If error message on display is not included in the list below, contact Globe Food Equipment.**

<b>312</b>	Label is remaining
<b>316</b>	Special price entered is equal to or over the preset PLU price
<b>396</b>	No USB found
<b>710</b>	Scale is out of labels
<b>1011</b>	The label is not in the proper position. Refer to Loading/Unloading Labels
<b>15029-0001</b>	Power scale off then turn scale back on.

# Tare Weight

Tare is the weight of an empty container. Tare is used to weigh food by removing the weight of the container, plate or bowl so you are left with just the food weight.

## EXAMPLE 1:

If your cafe has a sundae bar and the sundae bar is sold by weight, you can set up the PLU to subtract the weight of the sundae dish so the customer is paying for only the net weight of the sundae.

## EXAMPLE 2:

Potato Salad is sold in a plastic container. The weight of the container can be programmed into the PLU so that the container weight will automatically be deducted each time the product is weighed.

**NOTE: There are three different ways to manage the Tare Weight of a container.**

1. Key in a PLU number or select a PLU preset key.
  - a. Place the container on the weigh platter and select the Tare key on the Operator Keysheet.
  - b. Add the product on the weigh platter and press the Print key.
2. Program a Tare preset key. Refer to Preset Key Set Up.
3. Use the ScaleLink Pro 5 Lite Software to set up the Tare preset key. Refer to Edit Keyboard Layout, in the ScaleLink Pro 5 Lite Software User Guide for setup information.

# USB Scale Backup and Restore

**NOTE:** Data folders are used to store/restore the scale backup information PLUs, store information, label formats ect. Up to 7 data folders can be used to store/restore the backup information of the scale.



If a Data01, 02, 03 ect. folder exists on the USB device and the same data folder is selected to store the backup information, the previous backup information will be overwritten.

## Scale to USB

Scale to USB is used to backup a configuration file to an USB device.

1. Make sure the scale is plugged in, the weigh platter is on top of the scale, the scale is turned on.
2. Key in 6000 and press the Mode key. Display will show: B00 SETUP
3. Key in 495344 and press the PLU key.
4. Key in 27 and press the Enter key. Display will show: B27 FILE SAVE/LOAD
5. Press the Enter key. Display will show: B27-01 <USB-TO-SCALE>
6. Press the right arrow key on the Scale Set-Up Keysheet. Display will show: B27-02 <SCALE-TO-USB>
7. Press the Enter key. Display will show: B27-02-01 O/P SELECT >PL

**NOTE: Make sure USB device is installed in the USB port.**

8. Press the PLU key. Display will show: B27-200 SEL USB FOLDER
9. Use down arrow key on the Scale Set-Up Keysheet to select the folder that the data will be stored in (e.g. Data 01, 02, 03 ect.). Press the PLU key. Display will show: B27-02 <SCALE-TO-USB>

**NOTE: Scale will pause. After about five seconds backup will begin.**

10. Press the down arrow key on the Scale Set-Up Keysheet two times. Display will show: B27-02-02 DATA TYPE 1
11. Key in 1 then press the Enter key.
12. Press the down arrow key on the Scale Set-Up Keysheet once. Display will show: B27-02-03 MASTER MODE 2
13. Key in 1 then press the Enter key.
14. Press the down arrow key on the Scale Set-Up Keysheet once. Display will show: B27-02-04 EXCUTE >ZR
15. Press the →0 Zero key←. Display will show: 14011-0000 ENT OR CLR

**NOTE: Select Enter key to continue or CLR key to cancel the backup.**

16. Press the Enter key.

**NOTE: Scale will pause. After about five seconds backup will begin.**

17. Display will show: 14014-0000 ENT

**NOTE: Scale backup was successful and is now stored on the USB.**

18. Remove USB device from scale.
19. Press the Mode key four times to return to normal operation.
20. Install USB device into the USB port on PC to read backup information.

**NOTE: Data will be stored in the “Data01” folder that was selected above.**

## USB to Scale

USB to Scale is used to restore a configuration file from an USB device to the scale.

1. Make sure the scale is plugged in, the weigh platter is on top of the scale, the scale is turned on.
2. Key in 6000 and press the Mode key. Display will show: B00 SETUP

## USB Scale Backup and Restore

3. Key in 495344 and press the PLU key. Display will show: B00 SETUP
4. Key in 27 and press the Enter key. Display will show: B27 FILE SAVE/LOAD
5. Press the Enter key. Display will show: B27-01 <USB-TO-SCALE>
6. Press the Enter key. Display will show: B27-01-01 I/P SELECT >PL

**NOTE: Make sure USB device is installed in the USB port.**

7. Press the PLU key. Display will show: B27-100 SEL USB FOLDER

**NOTE: Scale will pause while reading USB.**

8. Use the down arrow key on the Scale Set-Up Keysheet to select the data folder (e.g. Data 01, 02, 03 ect.) to restore USB backup data. Press the PLU key. Display will show: B27-01 <USB-TO-SCALE>
9. Press the down arrow on the Scale Set-Up Keysheet two times. Display will show: B27-01-03 MASTER MODE
10. Key in 1 and press the Enter key.
11. Press the down arrow key once. Display will show: B27-01-04 EXCUTE > ZR
12. Press the →0 Zero key←. Display will show: 14011-0000 ENT OR CLR

**NOTE: Select Enter key to continue or CLR key to cancel the restore.**

13. Press the Enter key.

**NOTE: Scale will pause. After five seconds data folder from USB will begin to be upload to scale. Display will show the update in progress.**

14. Display will show: 14013-0000 ENT

**NOTE: Restore was successful and the data folder selected from the USB has been uploaded to the scale.**

15. Remove USB device from scale.
16. Press the Mode key four times to return to normal operation.

## Additional Features

Additional features are available for the GSP30B scale with the ScaleLink Pro 5 Lite (SLP-V Lite) software. The software is a PC provided program for creating, storing, and organizing your Ingredients Labels (for E13 labels only). This optional accessory is available for download at [www.GSP30B.gfesupport.com](http://www.GSP30B.gfesupport.com) with the purchase of this scale. Please contact a local Globe Representative for more information regarding this software.

### SLP-V Lite Software Features

- Scale data maintenance (Add/Edit/Delete information)
- Production total report
- Text import/export
- Scales campaign, Batch price change
- Scheduling functions, etc.
- Label format edition
- Logo image registration
- Supports multiple logos for each PLU
- Various character sizes that can be freely italicized, underlined, reversed and bolded
- Scale status monitoring illustrations memory capacity, thermal head status, and more.
- Error reports at scale
- Data and scale configuration backup/restore
- Scale firmware upgrades for up-to-date scale operating system
- Quick price and markdown change feature



## Limited Scale Warranty

Globe Food Equipment Company ("GFE") warrants to the original purchaser of new equipment that said equipment, when installed in accordance with our instructions within North America and subjected to normal use, is free from defects in material or workmanship for a period of 1 year (excludes wear items) from original installation date or factory shipment date (not to exceed 18 months) whichever comes first.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, WHETHER EXPRESSED OR IMPLIED. GFE EXPRESSLY DISCLAIMS ANY IMPLIED WARRANTY OF MERCHANTABILITY OR EXPRESSED OR IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

GFE'S OBLIGATION AND LIABILITY UNDER THIS WARRANTY IS EXPRESSLY LIMITED TO REPAIRING AND REPLACING EQUIPMENT WHICH PROVES TO BE DEFECTIVE IN MATERIAL OR WORKMANSHIP WITHIN THE APPLICABLE WARRANTY PERIOD. All repairs pursuant to this Warranty will be performed by an Authorized Designated GFE Service Location during normal working hours. IN NO EVENT SHALL GFE BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES TO BUYER OR ANY THIRD PARTY, INCLUDING, WITHOUT LIMITATION, LOSS OF PROPERTY, PERSONAL INJURY, LOSS OF BUSINESS OR PROFITS OR OTHER ECONOMIC LOSSES, OR STATUTORY OR EXEMPLARY DAMAGES, WHETHER IN NEGLIGENCE, WARRANTY, STRICT LIABILITY OR OTHERWISE.

This warranty is given only to the first purchaser from a retail dealer. No warranty is given to subsequent transferees.

This warranty does not cover product failures caused by: failure to maintain, neglect, abuse, damage due to excess water, fire, normal wear, improper set up and use. Periodic maintenance is not covered.

This Warranty is not in force until such time as a properly completed, digitally signed, and Installation/Warranty Registration has been received by GFE within 30 days from the date of installation. Complete warranty registration at:  
[www.globefoodequip.com/support/warranty-registration-form](http://www.globefoodequip.com/support/warranty-registration-form)

THE FOREGOING WARRANTY PROVISIONS ARE A COMPLETE AND EXCLUSIVE STATEMENT BETWEEN THE BUYER AND SELLER. GFE NEITHER ASSUMES NOR AUTHORIZES ANY PERSONS TO ASSUME FOR IT ANY OTHER OBLIGATION OR LIABILITY IN CONNECTION WITH SAID EQUIPMENT.

Example of items not covered under warranty, but not limited to just these items:

1. Acts of God, fire, water damage, burglary, accident, theft, vandalism.
2. Freight damage.
3. Improper installation or alteration of equipment.
4. Use of generic or after market parts.
5. Repairs made by anyone other than a GFE designated servicer.
6. Expendable wear parts including but not limited to display lights, keypad, com ports, etc.
7. Cleaning of equipment.
8. Misuse or abuse.

WARRANTY REGISTRATION  
SCAN THE QR CODE WITH YOUR MOBILE DEVICE OR GO TO  
[WWW.GLOBEFOODEQUIP.COM](http://WWW.GLOBEFOODEQUIP.COM)  
TO FILL OUT AND SUBMIT YOUR WARRANTY REGISTRATION.

[WWW.GLOBEFOODEQUIP.COM/SUPPORT/WARRANTY-REGISTRATION-FORM](http://WWW.GLOBEFOODEQUIP.COM/SUPPORT/WARRANTY-REGISTRATION-FORM)

