

# METRO<sup>®</sup> MAX Q "S" HOOK

## ASSEMBLY INSTRUCTIONS

1. Build the Free Standing unit.
2. Remove shelf mat(s) at level to be "S" hooked.
3. Loosen the wing nut on the "S" hook but do not remove.
4. Install the "S" hook to the shelf frame as shown in Fig. 1. **Use 2 "S" hooks per shelf level. Place "S" hooks outward near the shelf corners.**



Fig. 1

5. Build the "S" hook unit, placing shelves at the same level as the free standing unit. Remove the shelf mat(s).
6. Connect the shelf frames as shown in Fig. 2 at each shelf level.
7. Replace shelf mat(s). "S" hooks may need to be slid along shelf frame to clear the ribs on the underside of mat(s).



Fig. 2

8. Tighten the wing nut on the "S" hooks (Fig.3).



Fig. 3



**InterMetro Industries Corporation**  
North Washington Street, Wilkes-Barre, PA 18705  
For Product Information Call: 1-800-433-2232  
Visit Our Web Site: [www.intermetro.com](http://www.intermetro.com)

**ASSEMBLY INSTRUCTIONS**  
For MetroMaxQ "S" Hook

L01-285  
8/97

Information and specifications are subject to change without notice. Please confirm at time of order.