



CATALOG OF REPLACEMENT PARTS

1HF SERIES FRYER STAND ALONE


1HF50D	ML-136500
1HF50C	ML-136502
1HF85C	ML-136503

PRIOR MLS COVERED IN THIS MANUAL

1HF85D	ML-136501
--------	-----------

Table of Contents


5	CONTROL PANEL (NCC)
7	POWER SUPPLY BOX
9	BODY UNIT (1HF50C & 1HFD SERIES)
11	BODY UNIT (1HF85C)
13	TANK
15	HEATING ELEMENT ASSEMBLY
17	BASKETLIFT COMPONENTS
19	OIL RETURN AND ACCESSORIES (1HF85C)



CONTROL PANEL (NCC)

CONTROL PANEL (NCC)

ILLUS.	PART NO.	NAME OF PART	AMT.
PL-58876			
1	NS-046-89	Nut Assy. 6-32 KEPS	4
2	00-426815-000G1	Plate Assy. – Mounting (1HF50D).....	1
3	00-426815-000G2	Plate Assy. – Mounting (1HF85D).....	1
4	00-497745-00004	Overlay – Hobart (Boil) (1HF50D)	1
5	00-497745-00002	Overlay – Hobart (Filter)	1
6	00-913012-00006	Control Assy. – Solid State (Boil Button) (1HFD Series) (Incls. Item 4).....	1
7	00-913012-00007	Control Assy. – Solid State (Filter Button) (Incls. Item 5).....	1
8	00-497421-00002	Overlay – Control Panel.....	1
9	00-428906-00001	Overlay – Power	1
10	00-427755-000G1	Switch Assy. – Power.....	1
11	NS-046-89	Nut Assy. 6-32 KEPS	4
12	00-426815-000G1	Plate Assy. – Mounting (1HF50C).....	1
13	00-426815-000G2	Plate Assy. – Mounting (1HF85C).....	1
14	00-913012-00001	Control Assy. – Computer (Boil Button) (1HFC Series) (Incls. Item 15).....	1
15	00-497422-00002	Overlay – Control Panel (1HF50C/85C)	1
16	00-428906-00001	Overlay – Power	1
17	00-427755-000G1	Switch Assy.	1
	00-428280-000G1	Harness Assy. (1HF50C/85D).....	1
	00-428280-000G2	Harness Assy. – Interconnect	1
	00-428280-000G3	Harness Assy. – Lift Output (1HF50C).....	1




PL-58114

POWER SUPPLY BOX

POWER SUPPLY BOX

ILLUS. PL-58114	PART NO.	NAME OF PART	AMT.
1	00-497095-00002	Box – Power Supply (1HF85C/D).....	1
2	00-497095-00001	Box – Power Supply (1HF50C/D).....	1
3	00-411497-000C5	Contactor – 3 Pole (40 Amp., 230 V.).....	4
4	00-411497-000C3	Contactor – 3 Pole (40 Amp., 120 V.).....	4
5	SD-037-96	Self-Tapping Screw 8-18 x 3/4 Hex Hd., Type AB.....	8
6	00-497096-00001	Plate – Temperature Board (1HF50C/D).....	1
7	00-497096-00002	Plate – Temperature Board (1HF85C).....	1
8	SD-024-40	Self-Tapping Screw 6-32 x 5/8 Phil. Pan Hd., Type TT.....	4
9	00-427759-00001	Control – Interface.....	1
10	SC-060-23	Mach. Screw 4-40 x 1/4 Slotted Rd. Hd.	AR
11	00-416535-00004	Switch – Relay (24 V.).....	1
12	00-416535-00007	Switch – Relay (240 V.).....	1
13	NS-047-32	Lock Nut 4-40.....	AR
14	00-419317	Terminal – Stationary.....	1
15	SC-060-23	Mach. Screw 4-40 x 1/4 Slotted Rd. Hd.	AR
16	00-414208-00002	Barrier – Terminal.....	1
17	NS-009-07	Mach. Nut 6-32 Hex.....	2
18	SC-119-90	Mach. Screw 6-32 x 1 Pan Hd.	2
19	WL-004-40	Lockwasher #10 Medium.....	2
20	SD-036-80	Self-Tapping Screw 8-32 x 3/8 Hex Washer Hd., Type TT.....	4
21	FE-019-40	Fuse (15 Amp., 300 V.).....	2
22	FE-023-55	Holder – Fuse (15 Amp., 300 V.).....	2
23	00-428864-00004	Relay.....	1
24	00-411500-00012	Transformer (120 VAC, 28 V., 40 VA).....	1
25	00-411500-00013	Transformer (200-240 VAC, 28 V., 40 VA).....	1
26	SD-037-96	Self-Tapping Screw 8-18 x 3/4 Hex Washer Hd., Type AB.....	2
27	SD-036-80	Self-Tapping Screw 8-32 x 3/8 Hex Washer Hd., Type TT.....	4
28	00-497265-00001	Breaker.....	2
29	SD-036-96	Self-Tapping Screw 8-18 x 3/4 Hex Washer Hd.	2
30	00-417856-00001	Lug – Ground With Set Screw.....	1
31	SD-036-96	Self-Tapping Screw 8-18 x 3/4 Hex Washer Hd.	1
32	00-428271-00004	Lid Breaker Box With Breakers.....	1
33	SD-036-96	Self-Tapping Screw 8-18 x 3/4 Hex Washer Hd.	1
34	00-410472-00008	Block – Terminal (3 Pole).....	1
35	SD-036-96	Self-Tapping Screw 8-18 x 3/4 Hex Washer Hd.	2
36	00-497361-00002	Stand – Breaker.....	1
37	SD-036-96	Self-Tapping Screw 8-18 x 3/4 Hex Washer Hd.	1
38	00-428270-00002	Box – Breaker.....	1
39	00-497266-000G2	Box – Power Supply (208 V.) (1HF85C).....	1
40	00-497266-000G4	Box – Power Supply (480 V.).....	1
41	00-428271-00005	Lid – Breaker Box Small.....	1
42	SD-036-96	Self-Tapping Screw 8-18 x 3/4 Hex Washer Hd.	1
43	00-417856-00001	Lug – Ground With Set Screw.....	1
44	SD-036-96	Self-Tapping Screw 8-18 x 3/4 Hex Washer Hd.	1
45	00-428270-00003	Box – Breaker.....	1
46	00-497266-000G1	Box – Power Supply (208 V.) (1HF50C/D).....	1
47	00-410472-00008	Block – Terminal (3 Pole).....	1
48	SD-036-96	Self-Tapping Screw 8-18 x 3/4 Hex Washer Hd.	2
49	00-416535-00004	Switch – Relay (24 V.).....	1
	00-418346-00001	Cord – Power.....	1




PL-58117

BODY UNIT (1HF50C & 1HFD SERIES)

BODY UNIT (1HF50C & 1HFD SERIES)


ILLUS. PL-58117	PART NO.	NAME OF PART	AMT.
1	00-499223-00001	Basket – Twin (1HF50C/D)	AR
2	00-499223-00004	Basket – Twin (HFD85D)	AR
3	00-499223-00011	Basket – Single (1HF85)	AR
4	00-499223-00009	Basket – Single (1HF50C/D)	AR
5	00-421912-000G1	Hanger – Single Basket (1HF85D)	1
6	00-421911-000G1	Hanger – Single Basket (1HF50C/D)	1
7	00-422020-000G4	Flue Wrap (SST) (1HF85D)	1
8	00-422021-00002	Flue Wrap (SST) (1HF50C/D)	1
9	SD-036-96	Self-Tapping Screw 8-18 x 3/4 Hex Hd., Type AB	2
10	00-420596-00004	Body – Side (SST) (RH)	1
11	RS-033-04	Rivet – Pop	1
12	00-497296-00001	Magnet – Door	1
13	00-497296-000G1	Magnet Assy.	1
14	SD-032-07	Self-Tapping Screw 10-24 x 1/2 Hex Washer Hd., Type TT	10
15	00-417014-00001	Bracket – Rear Support (1HF50C/D)	1
16	00-418320-00001	Bracket – Rear Support (1HF85D)	1
17	00-427825-00001	Bracket – Power Supply – Rear	1
18	00-427824-00001	Bracket – Power Supply – Front	1
19	00-416950-00001	Body – Bottom (Rear) (1HF50C/D)	1
20	00-419652	Body – Bottom (Rear) (1HF85D)	1
21	00-427886-00001	Body – Bottom (Front) (1HF50C/D)	1
22	00-428152-00001	Body – Bottom (Front) (1HF85D)	1
23	00-413112-00012	Leg (6 In.) (SST)	4
24	00-421893-00001	Plate – Mount – Casters (1HF50C & 1HF85D)	2
25	00-421893-00002	Caster (No Brake) (1HF50C & 1HF85D)	2
26	00-420769-00001	Bumper – Rubber	1
27	00-419653	Handle	1
28	RS-033-02	Rivet – Pop	4
29	00-499487-000G1	Door Assy. (SST) (1HF50C/D)	1
30	00-499487-000G5	Door Assy. (1HF85D)	1
31	00-426806-000G1	Frame – Front (1HF50C/D)	1
32	00-426806-000G4	Frame – Front (1HF85D)	1
33	00-420596-00003	Body – Side (SST) (LH)	1
34	SD-036-03	Self-Tapping Screw 8-18 x 3/8 Hex Washer Hd., Type AB	8
35	00-427883-00002	Screen – Basket Support (1HF50C/D)	1
36	00-427883-00004	Rack – Basket (1HF85D)	1
	00-416737-00002	Bracket – Thermistor	1
	00-422737-00002	Probe – Thermistor (1HF50C/D)	1
	00-422737-00001	Probe – Thermistor (1HF85C/D)	1



BODY UNIT (1HF85C)

BODY UNIT (1HF85C)

ILLUS. PL-58116	PART NO.	NAME OF PART	AMT.
1	00-499223-00004	Basket – Twin.....	AR
2	00-499223-00011	Basket – Single.....	AR
3	00-421912-000G1	Hanger – Single Basket.....	1
4	00-422020-000G4	Flue Wrap (SST) (HFD85/85F & HFC85/85F).....	1
5	SD-036-96	Self-Tapping Screw 8-18 x 3/4 Hex Hd., Type AB.....	2
6	00-419777-00004	Body – Side (SST) (RH).....	1
7	SD-032-07	Self-Tapping Screw 10-24 x 1/2 Hex Washer Hd., Type TT.....	10
8	00-418320-00001	Bracket – Rear Support.....	1
9	00-420839-000G2	Base Assy.	1
10	00-497296-00001	Magnet – Door.....	1
11	00-497296-000G1	Magnet Assy.....	1
12	RS-033-04	Rivet – Pop.....	1
13	00-413112-00007	Leg (6 1/4 In.).....	4
14	00-420769-00001	Bumper – Rubber.....	1
15	00-419653	Handle.....	1
16	RS-033-04	Rivet – Pop (0.187).....	4
17	00-499487-000G7	Door Assy. – With Hinge (LH).....	1
18	00-426806-000G4	Frame Assy. – Front.....	1
19	00-419777-00003	Body – Side (SST) (LH).....	1
20	SD-036-03	Self-Tapping Screw 8-18 x 3/8 Hex Washer Hd., Type AB.....	8
21	00-427883-00004	Screen – Basket Support.....	1




PL-58113

TANK

TANK


ILLUS. PL-58113	PART NO.	NAME OF PART	AMT.
1	00-421844-000G3	Tank Assy. (1HF50C/D).....	1
2	00-421842-000G3	Tank Assy. (1HF85C/D).....	1
3	00-410863-00002	Channel – Grease (1HF50C/D).....	1
4	00-410863-00007	Channel – Grease (Spec) (1HF85C/D).....	1
5	FP-028-14	Plug – Pipe 1/2 Sq. Hd.	AR
6	00-402570-00003	Eye Bolt	AR
7	NS-047-69	Lock Nut 6-32 Hex	AR
8	00-406363-00001	Spring – Door (Long)	AR
9	00-426803-000G2	Valve Assy. (Incls. Items 10 & 11).....	1
10	00-426805-000G1	Switch Assy.	1
11	00-426801-00002	Magnet – Switch Element Head	1



HEATING ELEMENT ASSEMBLY

HEATING ELEMENT ASSEMBLY

ILLUS.	PART NO.	NAME OF PART	AMT.
PL-58112			
1	00-421829-000G1	Element Head Assy. (1HF85C/D)	1
2	00-422322-000G1	Element Head Assy. (1HF50C/D)	1
3	00-416782-00001	Bracket – Hi-Limit	AR
4	00-416782-00002	Bracket – Hi-Limit	1
5	00-414177-00001	Clamp – Bottom Element Assy. (HFD50/50F & HFC50/50F).....	2
6	00-422380-00002	Clamp – Bottom Element Assy. (HFD85/85F & HFC85/85F).....	1
7	00-422381-000G1	Clamp – Top Element Assy. (HFD85/85F & HFC85/85F)	4
8	00-414178-000G2	Clamp – Top Element Assy. (HFD50/50F & HFC50/50F)	4
9	00-416741-000G9	Element Assy. (208 V., 8500 kW) (1HF50C/D)	2
10	00-416741-00G12	Element Assy. (480 V., 8500 kW) (1HF50C/D)	2
11	00-421892-000G1	Element Assy. (208 V., 12000 kW) (1HF85C/D)	2
12	00-421892-000G4	Element Assy. (480 V., 12000 kW) (1HF85C/D)	2
	00-414146-00002	Thermostat Hi-Limit	1
	00-426801-00001	Switch – Wired	1
	00-426801-00002	Magnet – Switch Element Head	1
	00-422380-00001	Clamp – Rear Lower Element (1HF85C).....	1
	00-422381-000G2	Clamp – Top Element Assy. With Guard (1HF85C).....	1
	00-422414-00001	Clamp – Front Lower Element (1HF85C)	1
	00-427764-00001	Clamp – Front Lower Element (1HF50C/D).....	1
	00-416736-00001	Gasket – Element Flange	4
	00-422737-00001	Probe – Thermistor	1




PL-58115

BASKETLIFT COMPONENTS

BASKETLIFT COMPONENTS

ILLUS. PL-58115	PART NO.	NAME OF PART	AMT.
1	PB-005-29	Plug – Button	1
2	SC-047-34	Set Screw $\frac{5}{16}$ -18 x $\frac{1}{2}$ Hdls., Cup Pt.	1
3	00-427877-000G1	Lift Assy. (Single)	1
4	00-418503-00002	Tube.....	1
5	PB-004-04	Plug Button ($\frac{1}{4}$).....	2
6	SD-032-07	Self-Tapping Screw 10-24 x $\frac{1}{2}$ Hex Washer Hd., Type TT	6
7	00-422247-000G1	Bearing Support Assy.....	1
8	SD-036-03	Self-Tapping Screw 8-18 x $\frac{3}{8}$ Hex Washer Hd., Type AB.....	10
9	SC-109-10	Mach. Screw 6-32 x $\frac{3}{8}$ Pan Hd.....	1
10	NS-009-07	Mach. Nut 6-32 Hex.....	1
11	00-078752-00012	Clamp – Cable	1
12	00-418159-00001	Block – Cam Switch.....	1
13	00-411496-000F3	Switch – Micro	1
14	SC-112-90	Mach. Screw 4-40 x 1 Pan Hd.	2
15	NS-009-12	Mach. Nut 8-32 Hex.....	2
16	00-418123-000G1	Plate – Motor	1
17	SD-032-07	Self-Tapping Screw 10-24 x $\frac{1}{2}$ Hex Washer Hd., Type TT	2
18	SC-037-80	Cap Screw 10-24 x $\frac{1}{2}$ Hex Hd.	6
19	00-418156-00001	Gear – Motor (480 V.)	1
20	00-418156-00003	Gear – Motor (208/240 V., 50/60 Hz.).....	1
21	00-418517-00001	Shroud – Motor.....	1
22	SD-032-07	Self-Tapping Screw 10-24 x $\frac{1}{2}$ Hex Washer Hd., Type TT	2
23	00-418513-00001	Base – Motor (21 In.)	1
24	SC-037-80	Cap Screw 10-24 x $\frac{1}{2}$ Hex Hd.	2
25	00-418510-00001	Wrap – Bottom (HFD85/85F & HFC85/85F).....	1
26	NS-009-07	Mach. Nut 6-32 Hex.....	2
27	00-416535-00004	Relay S.P.D.T. 24 V. Coil (Located on rear of panel)	1
28	SC-109-10	Mach. Screw 6-32 x $\frac{3}{8}$ Pan Hd.....	2
29	SC-018-47	Mach. Screw 10-32 x $\frac{3}{4}$ Pan Hd.....	4
30	SD-036-03	Self-Tapping Screw 8-18 x $\frac{3}{8}$ Hex Washer Hd., Type AB.....	14
31	SC-037-80	Cap Screw 10-24 x $\frac{1}{2}$ Hex Hd.	2
32	00-418482-00001	Grommet.....	1
33	00-418475-000G1	Crank-Arm Assy.	1
34	SC-055-02	Set Screw $\frac{1}{4}$ -20 x $\frac{1}{4}$ Hdls., Cup Pt.....	2
35	NS-047-73	Lock Nut $\frac{5}{16}$ -18 Hex.....	1
36	WS-004-33	Washer.....	1
37	00-418477-000G2	Coupler Assy.	1
38	WS-004-33	Washer.....	1
39	NS-047-73	Lock Nut $\frac{5}{16}$ -18 Hex.....	1
40	00-422018-00001	Wrap – Top.....	1
	00-422376-00001	Brace – Spring Retainer (1HF50C/D)	1
	00-422377-00001	Brace – Spring Retainer (1HF85C).....	1



OIL RETURN AND ACCESSORIES (1HF85C)

OIL RETURN AND ACCESSORIES (1HF85C)

ILLUS.	PART NO.	NAME OF PART	AMT.
PL-58118			
1	00-419251-00001	Elbow – 1/2 NPTF Male Swivel	1
2	FP-035-96	Pipe 1/2 x 2 1/2 TBE	1
3	00-418786-00001	Valve – Check (Ball Cone).....	1
4	00-419211-00001	Adapter (Pipe to Flare)	1
5	00-418966-00002	Oil Return Line	1
6	SD-032-07	Self-Tapping Screw 10-24 x 1/2 Hex Washer Hd., Type TT	2
7	00-078752-00003	Clamp – Cable	2
8	00-521820	U-Bolt 1/4-20	1
9	00-420588-000G1	Bracket – Oil Return	1
10	00-418791-000G1	Quick Disconnect Assy.....	1
11	NS-046-52	Nut 1/4-20 Hex KEPS.....	2
12	SD-032-07	Self-Tapping Screw 10-24 x 1/2 Hex Washer Hd., Type TT	4
13	NS-044-09	Nut Assy. 10-24 Hex KEPS.....	4
	00-423268-00001	Pipe – Drain	1
	00-499486-00001	Clip – Drain Pipe	1
	00-956636-00001	Bracket – Bulb Locator	1

