



# CATALOG OF REPLACEMENT PARTS

## 1HF SERIES FRYER STAND ALONE

|        |           |
|--------|-----------|
| 1HF50D | ML-136500 |
| 1HF50C | ML-136502 |
| 1HF85C | ML-136503 |


### PRIOR MLS COVERED IN THIS MANUAL

|        |           |
|--------|-----------|
| 1HF85D | ML-136501 |
|--------|-----------|



### **Table of Contents**

|    |                                     |
|----|-------------------------------------|
| 5  | CONTROL PANEL (NCC)                 |
| 7  | POWER SUPPLY BOX                    |
| 9  | BODY UNIT (1HF50C & 1HFD SERIES)    |
| 11 | BODY UNIT (1HF85C)                  |
| 13 | TANK                                |
| 15 | HEATING ELEMENT ASSEMBLY            |
| 17 | BASKETLIFT COMPONENTS               |
| 19 | OIL RETURN AND ACCESSORIES (1HF85C) |




PL-58876

## CONTROL PANEL (NCC)

**CONTROL PANEL (NCC)**

| ILLUS.   | PART NO.        | NAME OF PART                                                                 | AMT. |
|----------|-----------------|------------------------------------------------------------------------------|------|
| PL-58876 |                 |                                                                              |      |
| 1        | NS-046-89       | Nut Assy. 6-32 KEPS .....                                                    | 4    |
| 2        | 00-426815-000G1 | Plate Assy. – Mounting (1HF50D).....                                         | 1    |
| 3        | 00-426815-000G2 | Plate Assy. – Mounting (1HF85D).....                                         | 1    |
| 4        | 00-497745-00004 | Overlay – Hobart (Boil) (1HF50D) .....                                       | 1    |
| 5        | 00-497745-00002 | Overlay – Hobart (Filter) .....                                              | 1    |
| 6        | 00-913012-00006 | Control Assy. – Solid State (Boil Button) (1HFD Series) (Incls. Item 4)..... | 1    |
| 7        | 00-913012-00007 | Control Assy. – Solid State (Filter Button) (Incls. Item 5).....             | 1    |
| 8        | 00-497421-00002 | Overlay – Control Panel.....                                                 | 1    |
| 9        | 00-428906-00001 | Overlay – Power .....                                                        | 1    |
| 10       | 00-427755-000G1 | Switch Assy. – Power.....                                                    | 1    |
| 11       | NS-046-89       | Nut Assy. 6-32 KEPS .....                                                    | 4    |
| 12       | 00-426815-000G1 | Plate Assy. – Mounting (1HF50C).....                                         | 1    |
| 13       | 00-426815-000G2 | Plate Assy. – Mounting (1HF85C).....                                         | 1    |
| 14       | 00-913012-00001 | Control Assy. – Computer (Boil Button) (1HFC Series) (Incls. Item 15).....   | 1    |
| 15       | 00-497422-00002 | Overlay – Control Panel (1HF50C/85C) .....                                   | 1    |
| 16       | 00-428906-00001 | Overlay – Power .....                                                        | 1    |
| 17       | 00-427755-000G1 | Switch Assy. ....                                                            | 1    |
|          | 00-428280-000G1 | Harness Assy. (1HF50C/85D).....                                              | 1    |
|          | 00-428280-000G2 | Harness Assy. – Interconnect .....                                           | 1    |
|          | 00-428280-000G3 | Harness Assy. – Lift Output (1HF50C).....                                    | 1    |




PL-58114

## POWER SUPPLY BOX

## POWER SUPPLY BOX


| ILLUS.<br>PL-58114 | PART NO.        | NAME OF PART                                               | AMT. |
|--------------------|-----------------|------------------------------------------------------------|------|
| 1                  | 00-497095-00002 | Box – Power Supply (1HF85C/D).....                         | 1    |
| 2                  | 00-497095-00001 | Box – Power Supply (1HF50C/D).....                         | 1    |
| 3                  | 00-411497-000C5 | Contactor – 3 Pole (40 Amp., 230 V.).....                  | 4    |
| 4                  | 00-411497-000C3 | Contactor – 3 Pole (40 Amp., 120 V.).....                  | 4    |
| 5                  | SD-037-96       | Self-Tapping Screw 8-18 x 3/4 Hex Hd., Type AB.....        | 8    |
| 6                  | 00-497096-00001 | Plate – Temperature Board (1HF50C/D).....                  | 1    |
| 7                  | 00-497096-00002 | Plate – Temperature Board (1HF85C).....                    | 1    |
| 8                  | SD-024-40       | Self-Tapping Screw 6-32 x 5/8 Phil. Pan Hd., Type TT.....  | 4    |
| 9                  | 00-427759-00001 | Control – Interface.....                                   | 1    |
| 10                 | SC-060-23       | Mach. Screw 4-40 x 1/4 Slotted Rd. Hd. ....                | AR   |
| 11                 | 00-416535-00004 | Switch – Relay (24 V.).....                                | 1    |
| 12                 | 00-416535-00007 | Switch – Relay (240 V.).....                               | 1    |
| 13                 | NS-047-32       | Lock Nut 4-40.....                                         | AR   |
| 14                 | 00-419317       | Terminal – Stationary.....                                 | 1    |
| 15                 | SC-060-23       | Mach. Screw 4-40 x 1/4 Slotted Rd. Hd. ....                | AR   |
| 16                 | 00-414208-00002 | Barrier – Terminal.....                                    | 1    |
| 17                 | NS-009-07       | Mach. Nut 6-32 Hex.....                                    | 2    |
| 18                 | SC-119-90       | Mach. Screw 6-32 x 1 Pan Hd. ....                          | 2    |
| 19                 | WL-004-40       | Lockwasher #10 Medium.....                                 | 2    |
| 20                 | SD-036-80       | Self-Tapping Screw 8-32 x 3/8 Hex Washer Hd., Type TT..... | 4    |
| 21                 | FE-019-40       | Fuse (15 Amp., 300 V.).....                                | 2    |
| 22                 | FE-023-55       | Holder – Fuse (15 Amp., 300 V.).....                       | 2    |
| 23                 | 00-428864-00004 | Relay.....                                                 | 1    |
| 24                 | 00-411500-00012 | Transformer (120 VAC, 28 V., 40 VA).....                   | 1    |
| 25                 | 00-411500-00013 | Transformer (200-240 VAC, 28 V., 40 VA).....               | 1    |
| 26                 | SD-037-96       | Self-Tapping Screw 8-18 x 3/4 Hex Washer Hd., Type AB..... | 2    |
| 27                 | SD-036-80       | Self-Tapping Screw 8-32 x 3/8 Hex Washer Hd., Type TT..... | 4    |
| 28                 | 00-497265-00001 | Breaker.....                                               | 2    |
| 29                 | SD-036-96       | Self-Tapping Screw 8-18 x 3/4 Hex Washer Hd. ....          | 2    |
| 30                 | 00-417856-00001 | Lug – Ground With Set Screw.....                           | 1    |
| 31                 | SD-036-96       | Self-Tapping Screw 8-18 x 3/4 Hex Washer Hd. ....          | 1    |
| 32                 | 00-428271-00004 | Lid Breaker Box With Breakers.....                         | 1    |
| 33                 | SD-036-96       | Self-Tapping Screw 8-18 x 3/4 Hex Washer Hd. ....          | 1    |
| 34                 | 00-410472-00008 | Block – Terminal (3 Pole).....                             | 1    |
| 35                 | SD-036-96       | Self-Tapping Screw 8-18 x 3/4 Hex Washer Hd. ....          | 2    |
| 36                 | 00-497361-00002 | Stand – Breaker.....                                       | 1    |
| 37                 | SD-036-96       | Self-Tapping Screw 8-18 x 3/4 Hex Washer Hd. ....          | 1    |
| 38                 | 00-428270-00002 | Box – Breaker.....                                         | 1    |
| 39                 | 00-497266-000G2 | Box – Power Supply (208 V.) (1HF85C).....                  | 1    |
| 40                 | 00-497266-000G4 | Box – Power Supply (480 V.).....                           | 1    |
| 41                 | 00-428271-00005 | Lid – Breaker Box Small.....                               | 1    |
| 42                 | SD-036-96       | Self-Tapping Screw 8-18 x 3/4 Hex Washer Hd. ....          | 1    |
| 43                 | 00-417856-00001 | Lug – Ground With Set Screw.....                           | 1    |
| 44                 | SD-036-96       | Self-Tapping Screw 8-18 x 3/4 Hex Washer Hd. ....          | 1    |
| 45                 | 00-428270-00003 | Box – Breaker.....                                         | 1    |
| 46                 | 00-497266-000G1 | Box – Power Supply (208 V.) (1HF50C/D).....                | 1    |
| 47                 | 00-410472-00008 | Block – Terminal (3 Pole).....                             | 1    |
| 48                 | SD-036-96       | Self-Tapping Screw 8-18 x 3/4 Hex Washer Hd. ....          | 2    |
| 49                 | 00-416535-00004 | Switch – Relay (24 V.).....                                | 1    |
|                    | 00-418346-00001 | Cord – Power.....                                          | 1    |



**BODY UNIT (1HF50C & 1HFD SERIES)**

### BODY UNIT (1HF50C & 1HFD SERIES)


| ILLUS.<br>PL-58117 | PART NO.        | NAME OF PART                                                 | AMT. |
|--------------------|-----------------|--------------------------------------------------------------|------|
| 1                  | 00-499223-00001 | Basket – Twin (1HF50C/D) .....                               | AR   |
| 2                  | 00-499223-00004 | Basket – Twin (HFD85D) .....                                 | AR   |
| 3                  | 00-499223-00011 | Basket – Single (1HF85) .....                                | AR   |
| 4                  | 00-499223-00009 | Basket – Single (1HF50C/D) .....                             | AR   |
| 5                  | 00-421912-000G1 | Hanger – Single Basket (1HF85D) .....                        | 1    |
| 6                  | 00-421911-000G1 | Hanger – Single Basket (1HF50C/D) .....                      | 1    |
| 7                  | 00-422020-000G4 | Flue Wrap (SST) (1HF85D) .....                               | 1    |
| 8                  | 00-422021-00002 | Flue Wrap (SST) (1HF50C/D) .....                             | 1    |
| 9                  | SD-036-96       | Self-Tapping Screw 8-18 x 3/4 Hex Hd., Type AB .....         | 2    |
| 10                 | 00-420596-00004 | Body – Side (SST) (RH) .....                                 | 1    |
| 11                 | RS-033-04       | Rivet – Pop .....                                            | 1    |
| 12                 | 00-497296-00001 | Magnet – Door .....                                          | 1    |
| 13                 | 00-497296-000G1 | Magnet Assy. ....                                            | 1    |
| 14                 | SD-032-07       | Self-Tapping Screw 10-24 x 1/2 Hex Washer Hd., Type TT ..... | 10   |
| 15                 | 00-417014-00001 | Bracket – Rear Support (1HF50C/D) .....                      | 1    |
| 16                 | 00-418320-00001 | Bracket – Rear Support (1HF85D) .....                        | 1    |
| 17                 | 00-427825-00001 | Bracket – Power Supply – Rear .....                          | 1    |
| 18                 | 00-427824-00001 | Bracket – Power Supply – Front .....                         | 1    |
| 19                 | 00-416950-00001 | Body – Bottom (Rear) (1HF50C/D) .....                        | 1    |
| 20                 | 00-419652       | Body – Bottom (Rear) (1HF85D) .....                          | 1    |
| 21                 | 00-427886-00001 | Body – Bottom (Front) (1HF50C/D) .....                       | 1    |
| 22                 | 00-428152-00001 | Body – Bottom (Front) (1HF85D) .....                         | 1    |
| 23                 | 00-413112-00012 | Leg (6 In.) (SST) .....                                      | 4    |
| 24                 | 00-421893-00001 | Plate – Mount – Casters (1HF50C & 1HF85D) .....              | 2    |
| 25                 | 00-421893-00002 | Caster (No Brake) (1HF50C & 1HF85D) .....                    | 2    |
| 26                 | 00-420769-00001 | Bumper – Rubber .....                                        | 1    |
| 27                 | 00-419653       | Handle .....                                                 | 1    |
| 28                 | RS-033-02       | Rivet – Pop .....                                            | 4    |
| 29                 | 00-499487-000G1 | Door Assy. (SST) (1HF50C/D) .....                            | 1    |
| 30                 | 00-499487-000G5 | Door Assy. (1HF85D) .....                                    | 1    |
| 31                 | 00-426806-000G1 | Frame – Front (1HF50C/D) .....                               | 1    |
| 32                 | 00-426806-000G4 | Frame – Front (1HF85D) .....                                 | 1    |
| 33                 | 00-420596-00003 | Body – Side (SST) (LH) .....                                 | 1    |
| 34                 | SD-036-03       | Self-Tapping Screw 8-18 x 3/8 Hex Washer Hd., Type AB .....  | 8    |
| 35                 | 00-427883-00002 | Screen – Basket Support (1HF50C/D) .....                     | 1    |
| 36                 | 00-427883-00004 | Rack – Basket (1HF85D) .....                                 | 1    |
|                    | 00-416737-00002 | Bracket – Thermistor .....                                   | 1    |
|                    | 00-422737-00002 | Probe – Thermistor (1HF50C/D) .....                          | 1    |
|                    | 00-422737-00001 | Probe – Thermistor (1HF85C/D) .....                          | 1    |



**BODY UNIT (1HF85C)**

**BODY UNIT (1HF85C)**

| ILLUS.<br>PL-58116 | PART NO.        | NAME OF PART                                                | AMT. |
|--------------------|-----------------|-------------------------------------------------------------|------|
| 1                  | 00-499223-00004 | Basket – Twin.....                                          | AR   |
| 2                  | 00-499223-00011 | Basket – Single.....                                        | AR   |
| 3                  | 00-421912-000G1 | Hanger – Single Basket.....                                 | 1    |
| 4                  | 00-422020-000G4 | Flue Wrap (SST) (HFD85/85F & HFC85/85F).....                | 1    |
| 5                  | SD-036-96       | Self-Tapping Screw 8-18 x 3/4 Hex Hd., Type AB.....         | 2    |
| 6                  | 00-419777-00004 | Body – Side (SST) (RH).....                                 | 1    |
| 7                  | SD-032-07       | Self-Tapping Screw 10-24 x 1/2 Hex Washer Hd., Type TT..... | 10   |
| 8                  | 00-418320-00001 | Bracket – Rear Support.....                                 | 1    |
| 9                  | 00-420839-000G2 | Base Assy. ....                                             | 1    |
| 10                 | 00-497296-00001 | Magnet – Door.....                                          | 1    |
| 11                 | 00-497296-000G1 | Magnet Assy.....                                            | 1    |
| 12                 | RS-033-04       | Rivet – Pop.....                                            | 1    |
| 13                 | 00-413112-00007 | Leg (6 1/4 In.).....                                        | 4    |
| 14                 | 00-420769-00001 | Bumper – Rubber.....                                        | 1    |
| 15                 | 00-419653       | Handle.....                                                 | 1    |
| 16                 | RS-033-04       | Rivet – Pop (0.187).....                                    | 4    |
| 17                 | 00-499487-000G7 | Door Assy. – With Hinge (LH).....                           | 1    |
| 18                 | 00-426806-000G4 | Frame Assy. – Front.....                                    | 1    |
| 19                 | 00-419777-00003 | Body – Side (SST) (LH).....                                 | 1    |
| 20                 | SD-036-03       | Self-Tapping Screw 8-18 x 3/8 Hex Washer Hd., Type AB.....  | 8    |
| 21                 | 00-427883-00004 | Screen – Basket Support.....                                | 1    |




PL-58113

TANK

## TANK


| ILLUS.<br>PL-58113 | PART NO.        | NAME OF PART                            | AMT. |
|--------------------|-----------------|-----------------------------------------|------|
| 1                  | 00-421844-000G3 | Tank Assy. (1HF50C/D).....              | 1    |
| 2                  | 00-421842-000G3 | Tank Assy. (1HF85C/D).....              | 1    |
| 3                  | 00-410863-00002 | Channel – Grease (1HF50C/D).....        | 1    |
| 4                  | 00-410863-00007 | Channel – Grease (Spec) (1HF85C/D)..... | 1    |
| 5                  | FP-028-14       | Plug – Pipe 1/2 Sq. Hd. ....            | AR   |
| 6                  | 00-402570-00003 | Eye Bolt .....                          | AR   |
| 7                  | NS-047-69       | Lock Nut 6-32 Hex .....                 | AR   |
| 8                  | 00-406363-00001 | Spring – Door (Long) .....              | AR   |
| 9                  | 00-426803-000G2 | Valve Assy. (Incls. Items 10 & 11)..... | 1    |
| 10                 | 00-426805-000G1 | Switch Assy. ....                       | 1    |
| 11                 | 00-426801-00002 | Magnet – Switch Element Head .....      | 1    |



### HEATING ELEMENT ASSEMBLY

## HEATING ELEMENT ASSEMBLY

| ILLUS.   | PART NO.        | NAME OF PART                                              | AMT. |
|----------|-----------------|-----------------------------------------------------------|------|
| PL-58112 |                 |                                                           |      |
| 1        | 00-421829-000G1 | Element Head Assy. (1HF85C/D) .....                       | 1    |
| 2        | 00-422322-000G1 | Element Head Assy. (1HF50C/D) .....                       | 1    |
| 3        | 00-416782-00001 | Bracket – Hi-Limit .....                                  | AR   |
| 4        | 00-416782-00002 | Bracket – Hi-Limit .....                                  | 1    |
| 5        | 00-414177-00001 | Clamp – Bottom Element Assy. (HFD50/50F & HFC50/50F)..... | 2    |
| 6        | 00-422380-00002 | Clamp – Bottom Element Assy. (HFD85/85F & HFC85/85F)..... | 1    |
| 7        | 00-422381-000G1 | Clamp – Top Element Assy. (HFD85/85F & HFC85/85F) .....   | 4    |
| 8        | 00-414178-000G2 | Clamp – Top Element Assy. (HFD50/50F & HFC50/50F) .....   | 4    |
| 9        | 00-416741-000G9 | Element Assy. (208 V., 8500 kW) (1HF50C/D) .....          | 2    |
| 10       | 00-416741-00G12 | Element Assy. (480 V., 8500 kW) (1HF50C/D) .....          | 2    |
| 11       | 00-421892-000G1 | Element Assy. (208 V., 12000 kW) (1HF85C/D) .....         | 2    |
| 12       | 00-421892-000G4 | Element Assy. (480 V., 12000 kW) (1HF85C/D) .....         | 2    |
|          | 00-414146-00002 | Thermostat Hi-Limit .....                                 | 1    |
|          | 00-426801-00001 | Switch – Wired .....                                      | 1    |
|          | 00-426801-00002 | Magnet – Switch Element Head .....                        | 1    |
|          | 00-422380-00001 | Clamp – Rear Lower Element (1HF85C).....                  | 1    |
|          | 00-422381-000G2 | Clamp – Top Element Assy. With Guard (1HF85C).....        | 1    |
|          | 00-422414-00001 | Clamp – Front Lower Element (1HF85C) .....                | 1    |
|          | 00-427764-00001 | Clamp – Front Lower Element (1HF50C/D).....               | 1    |
|          | 00-416736-00001 | Gasket – Element Flange .....                             | 4    |
|          | 00-422737-00001 | Probe – Thermistor .....                                  | 1    |




PL-58115

### BASKETLIFT COMPONENTS

## BASKETLIFT COMPONENTS

| ILLUS.<br>PL-58115 | PART NO.        | NAME OF PART                                                           | AMT. |
|--------------------|-----------------|------------------------------------------------------------------------|------|
| 1                  | PB-005-29       | Plug – Button .....                                                    | 1    |
| 2                  | SC-047-34       | Set Screw $\frac{5}{16}$ -18 x $\frac{1}{2}$ Hdls., Cup Pt. ....       | 1    |
| 3                  | 00-427877-000G1 | Lift Assy. (Single) .....                                              | 1    |
| 4                  | 00-418503-00002 | Tube.....                                                              | 1    |
| 5                  | PB-004-04       | Plug Button ( $\frac{1}{4}$ ).....                                     | 2    |
| 6                  | SD-032-07       | Self-Tapping Screw 10-24 x $\frac{1}{2}$ Hex Washer Hd., Type TT ..... | 6    |
| 7                  | 00-422247-000G1 | Bearing Support Assy.....                                              | 1    |
| 8                  | SD-036-03       | Self-Tapping Screw 8-18 x $\frac{3}{8}$ Hex Washer Hd., Type AB.....   | 10   |
| 9                  | SC-109-10       | Mach. Screw 6-32 x $\frac{3}{8}$ Pan Hd.....                           | 1    |
| 10                 | NS-009-07       | Mach. Nut 6-32 Hex.....                                                | 1    |
| 11                 | 00-078752-00012 | Clamp – Cable .....                                                    | 1    |
| 12                 | 00-418159-00001 | Block – Cam Switch.....                                                | 1    |
| 13                 | 00-411496-000F3 | Switch – Micro .....                                                   | 1    |
| 14                 | SC-112-90       | Mach. Screw 4-40 x 1 Pan Hd. ....                                      | 2    |
| 15                 | NS-009-12       | Mach. Nut 8-32 Hex.....                                                | 2    |
| 16                 | 00-418123-000G1 | Plate – Motor .....                                                    | 1    |
| 17                 | SD-032-07       | Self-Tapping Screw 10-24 x $\frac{1}{2}$ Hex Washer Hd., Type TT ..... | 2    |
| 18                 | SC-037-80       | Cap Screw 10-24 x $\frac{1}{2}$ Hex Hd. ....                           | 6    |
| 19                 | 00-418156-00001 | Gear – Motor (480 V.) .....                                            | 1    |
| 20                 | 00-418156-00003 | Gear – Motor (208/240 V., 50/60 Hz.).....                              | 1    |
| 21                 | 00-418517-00001 | Shroud – Motor.....                                                    | 1    |
| 22                 | SD-032-07       | Self-Tapping Screw 10-24 x $\frac{1}{2}$ Hex Washer Hd., Type TT ..... | 2    |
| 23                 | 00-418513-00001 | Base – Motor (21 In.) .....                                            | 1    |
| 24                 | SC-037-80       | Cap Screw 10-24 x $\frac{1}{2}$ Hex Hd. ....                           | 2    |
| 25                 | 00-418510-00001 | Wrap – Bottom (HFD85/85F & HFC85/85F).....                             | 1    |
| 26                 | NS-009-07       | Mach. Nut 6-32 Hex.....                                                | 2    |
| 27                 | 00-416535-00004 | Relay S.P.D.T. 24 V. Coil (Located on rear of panel) .....             | 1    |
| 28                 | SC-109-10       | Mach. Screw 6-32 x $\frac{3}{8}$ Pan Hd.....                           | 2    |
| 29                 | SC-018-47       | Mach. Screw 10-32 x $\frac{3}{4}$ Pan Hd.....                          | 4    |
| 30                 | SD-036-03       | Self-Tapping Screw 8-18 x $\frac{3}{8}$ Hex Washer Hd., Type AB.....   | 14   |
| 31                 | SC-037-80       | Cap Screw 10-24 x $\frac{1}{2}$ Hex Hd. ....                           | 2    |
| 32                 | 00-418482-00001 | Grommet.....                                                           | 1    |
| 33                 | 00-418475-000G1 | Crank-Arm Assy. ....                                                   | 1    |
| 34                 | SC-055-02       | Set Screw $\frac{1}{4}$ -20 x $\frac{1}{4}$ Hdls., Cup Pt.....         | 2    |
| 35                 | NS-047-73       | Lock Nut $\frac{5}{16}$ -18 Hex.....                                   | 1    |
| 36                 | WS-004-33       | Washer.....                                                            | 1    |
| 37                 | 00-418477-000G2 | Coupler Assy. ....                                                     | 1    |
| 38                 | WS-004-33       | Washer.....                                                            | 1    |
| 39                 | NS-047-73       | Lock Nut $\frac{5}{16}$ -18 Hex.....                                   | 1    |
| 40                 | 00-422018-00001 | Wrap – Top.....                                                        | 1    |
|                    | 00-422376-00001 | Brace – Spring Retainer (1HF50C/D) .....                               | 1    |
|                    | 00-422377-00001 | Brace – Spring Retainer (1HF85C).....                                  | 1    |



### OIL RETURN AND ACCESSORIES (1HF85C)

## OIL RETURN AND ACCESSORIES (1HF85C)

| ILLUS.   | PART NO.        | NAME OF PART                                                 | AMT. |
|----------|-----------------|--------------------------------------------------------------|------|
| PL-58118 |                 |                                                              |      |
| 1        | 00-419251-00001 | Elbow – 1/2 NPTF Male Swivel .....                           | 1    |
| 2        | FP-035-96       | Pipe 1/2 x 2 1/2 TBE .....                                   | 1    |
| 3        | 00-418786-00001 | Valve – Check (Ball Cone).....                               | 1    |
| 4        | 00-419211-00001 | Adapter (Pipe to Flare) .....                                | 1    |
| 5        | 00-418966-00002 | Oil Return Line .....                                        | 1    |
| 6        | SD-032-07       | Self-Tapping Screw 10-24 x 1/2 Hex Washer Hd., Type TT ..... | 2    |
| 7        | 00-078752-00003 | Clamp – Cable .....                                          | 2    |
| 8        | 00-521820       | U-Bolt 1/4-20 .....                                          | 1    |
| 9        | 00-420588-000G1 | Bracket – Oil Return .....                                   | 1    |
| 10       | 00-418791-000G1 | Quick Disconnect Assy.....                                   | 1    |
| 11       | NS-046-52       | Nut 1/4-20 Hex KEPS.....                                     | 2    |
| 12       | SD-032-07       | Self-Tapping Screw 10-24 x 1/2 Hex Washer Hd., Type TT ..... | 4    |
| 13       | NS-044-09       | Nut Assy. 10-24 Hex KEPS.....                                | 4    |
|          | 00-423268-00001 | Pipe – Drain .....                                           | 1    |
|          | 00-499486-00001 | Clip – Drain Pipe .....                                      | 1    |
|          | 00-956636-00001 | Bracket – Bulb Locator .....                                 | 1    |

