

PARTS LIST

for

KitchenAid®

4 1/2 QT. STAND MIXER

CLASSIC – TILT

MODELS:

K45SSWH-0 (White)
K45WSSWH-0 (White)
K45SSAC-0 (Almond Creme)
K45SSAL-0 (Almond)
K45SSDAC-0 (Almond Creme)
K45SSDAL-0 (Almond)
K45SSOB0 (Onyx Black)



FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS




KITCHENAID

ST. JOSEPH MICHIGAN 49085

COLOR VARIATION PARTS

FOR MODELS: K45SS__0, K45WSS__0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COLOR VARIATION PARTS


FOR MODELS: K45SS__0, K45WSS__0

Illus. No.	Part No.	DESCRIPTION
1		Motor Housing
	240291-1	White
	240291-16	Almond Creme
	240291-13	Onyx Black
2		Trim Band
	9702629	White
3		Planetary
	240286-1	White
	240286-18	Almond Creme
	240286-16	Onyx Black
4		End Cover
	240253-1	White
	240253-16	Almond Creme
	240253-14	Onyx Black
5		Lower Gearcase
	240350-4	White
	240350-62	Almond Creme
	240350-56	Onyx Black
6		Pedestal w/Feet
	3179260	White
	3179277	Almond Creme
	3179275	Onyx Black

Colors Subject To Change.
Any Color Not Listed is
No Longer Available.
If Additional Colors Are Added,
This Page Will Be Updated.

CASE, GEARING AND PLANETARY UNIT

FOR MODELS: K45SS__0, K45WSS__0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CASE, GEARING AND PLANETARY UNIT

FOR MODELS: K45SS__0, K45WSS__0


Illus. No.	Part No.	DESCRIPTION
1	**	Gearcase Motor Housing
2		Cap, Attachmnt Hub
	242765-2	Chrome
	242765-4	Painted
3		Thumb Screw
	9709194	Black
	9709196	Grey
4	**	Band, Trim
5	3180161	Washer
6	W10112253	Worm Gear
7	240308	Worm Gear Bracket And Bearing
8	9705444	Pin
9	240210-2	Shaft & Pinion
10	9705130	Gear, Attachment Hub Level
11	9709627	Bevel Pinion Center Gear
12	240026	Shaft, Vertical Center
13	240018-1	Pin (Vertical Center Shaft)
14	9705443	Pin, Groove
15	4162324	Gasket, Transmissn
16	67500-55	O-Ring
17	3180163	Washer
18	**	Lower Gear Case
19	103994	Screw
20	4176067	Shaft, Agitator
21	9703438	Ring, Retaining
22	9704677	Pin, Groove
23	4162914	Screw
24	**	Cover, End
25	311932	Screw
26	3400022	Screw
27	240309-2	Gear, Worm and Bracket
28	4160474	Center Shaft & O-Ring
29	8533914	Washer, Spring Lock
30	3400025	Screw
31	3400203	Screw, Set
32	9703903	Pinion, Gear Agitator Shaft
33	9706090	Washer
34	**	Planetary
35	240285	Ring, Planetary Drip
36	89411	Screw, Adjusting
37	9703904	Gear, Internal

**Refer to Pages 2 & 3

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND CONTROL PARTS

FOR MODELS: K45SS__0, K45WSS__0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND CONTROL PARTS


FOR MODELS: K45SS__0, K45WSS__0

Illus. No.	Part No.	DESCRIPTION
1	110679	Screw, Pivot
2	116241	Washer, Spring
3		Lever, Speed Control Assy
	9709276	Black
	9709277	Storm Grey
4	3183680	Spring, Control Plate
5	9704324	Washer, Ball Bearing (Front)
6	9708315	Armature & Bearing
7	3180162	Washer
8	16998	Stud, Governor Drive
9	3180526	Bracket, Bearing Assembly
10	240775-1	Seal, End
11	W10131078	Nut
12	3180238	Washer
13	240769	Screw
14	W10068270	Washer
15	3184176	Speed Link & Cam
16	240205	Spring, Flat
17	9702695	Field Assembly
18	4162634	Sleeve, Motor Stud
19	W10260958	Brush, w/Spring
20	9707926	Screw, Set
21	4162546	Brush Holder
22	3179908	Housing, Brush Holder
23	240680	Insert, Brush Holder
24	116286	Cap, Spring Seat
25	116287	Spring, Cap
26		Cap, Brush Holder
	3184212	Black
	3184211	White
27	W10068260	Screw
28	W10119326	Plate, Control Asy
29	17830	Governor Assembly
30	9706595	Board, Phase Control
31		Cord, Power
	W10164882	White
	W10164883	Black
32	3184609	Screw, Self Tap

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BASE AND PEDESTAL UNIT

FOR MODELS: K45SS__0, K45WSS__0



Illus. No.	Part No.	DESCRIPTION
1	9709785	Literature Parts
	8212369	Use & Care, Trilin
	9708470	Repair Parts List
3	4163337	Beater, Flat
4	3400020	Bowl, 4 1/2 Qt.
5	W10191926	Screw
6	9709707	Screw Cap Kit
7	9706446	Foot, Base
8	9708471	Whip, Wire
9	9709055	Hook, Dough
10		Latch
11		Latch, Link & Lever
	24452	Black
	24452-2	Storm Grey
12	110679	Screw, Pivot
13	116241	Washer, Spring
14	8533912	Washer
15	103993	Screw, Latch Bearing
16	24450	Link, Latch
17		Lever, Latch
	9709280	Black
	9709281	Storm Grey
18	16910	Pin, Hinge
19	**	Pedestal

**REFER TO PAGES 2 & 3

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ACCESSORY PARTS

FOR MODELS: K45SS__0, K45WSS__0

Illus. No.	Part No.	DESCRIPTION
FOLLOWING PARTS NOT ILLUSTRATED		
4164839		Speed Disc (Service Tool)
4160588		Grease, Planetary
4164778		Mixer Attachment Pak (Includes Food Grinder (FGA), Food Strainer (FVSP), And Vegetable Slicer, (RVSA) (FPPA)
4164749		Food Grinder (FGA)
8211924		Grain Mill (KGMA)
4164768		Pasta Maker And Food Grinder (Includes SNP Pasta Maker Plates) (SNFGA)
4164775		Fruit/Vegetable Strainer Parts (Use With FGA Model Only) (FVSP)
4164750		Rotor Slicer/ Shredder (With 4 Standard Cones) Fine Shredder, Coarse Shredder, Thick Slicer, and Thin Slicer (RVSA)
9704568		Pouring Shield (KPS2CL)
4164824		Pasta Maker Plates (SNPA)
4164774		Fruit/Vegetable Strainer and Food Grinder (FVSFGA)
3180617		Cover, Decorative (Cotton Polyester)
4162838		Food Tray (FT)
4164748		Juicer (JE)
4164747		Can Opener (CO)
4164803		Sausage Stuffer Kit (SSA)
8212519		Ice Cream Maker (KICA0WH0)
3177924		Bowl Cover, Plastic Non-Sealing
4163337		Bowl, Stainless With Handle
3180262		Bowl, 3 Qt.
4162160		Bowl, Satin Stainless

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST