

the Smoking Gun™ Cloche

Care & Cleaning



The Smoking Gun™ Cloche is made of Borosilicate glass, which offers an improved resistance to temperature changes.

Thanks to the glass thickness and material, the Smoking Gun™ Cloche can be washed with any cleaning product and is even dishwasher safe.

NOTE:

Do not use any hard scouring pad to clean the glass of the Smoking Gun™ Cloche.

Do not use chlorine or any grease remover containing chlorine to wash the silicone valve.

To use the Smoking Gun™ Cloche, simply connect the Smoking Gun™ hose to the cloche valve. Operate the Smoking Gun™ as usual.

The Smoking Gun™ Cloche est fabriquée en verre borosilicate qui offre une résistance accrue aux chocs thermiques.

Grâce à l'épaisseur du verre et à son matériau, the Smoking Gun™ Cloche peut être lavée avec tout produit de nettoyage et va même au lave-vaisselle.

NOTE:

N'utilisez pas de tampon à récurer abrasif pour nettoyer the Smoking Gun™ Cloche.

N'utilisez pas de chlore ou de dégraissant contenant du chlore pour laver la valve en silicone de la cloche.

Pour utiliser the Smoking Gun™ Cloche, vous n'avez qu'à connecter le tuyau du the Smoking Gun™ à la valve de la cloche. Puis faites fonctionner le diffuseur de fumée the Smoking Gun™ comme d'habitude.

Breville | **PolyScience**™

www.breville.com www.polyscienceculinary.com