

**1 'AAA'  
battery  
(Included)**

5806

NOTE: There is a static cling label over the digital display and some units have a strip under the battery door to prevent battery drain during shipping. Please remove both before use.

Since 1851, Taylor has been producing quality and accurate thermometers and timers for your kitchens. Our professional standards will provide you with durable and quality performance that you can rely on for great cooking results.

## INSTRUCTIONS FOR USE:

1. Press 'M' button to set minutes.
2. Press 'S' button to set seconds.
3. Press 'START/STOP' to start timer.
4. To pause the timer, press 'START/STOP'. Press again to restart timing.
5. When alarm beeps, press 'START/STOP' to turn off alarm. The timer will recall the last set time.
6. Press 'M' and 'S' at the same time to reset to zero.
7. The timer will also count up. Press 'START/STOP' when the display reads "00:00" and the timer will count up. Press 'START/STOP' again to pause and restart timing. Press 'M' and 'S' at the same time to reset to zero.
8. The timer will time up to 99 minutes and 59 seconds.