

Scotch-Brite™

Griddle Polishing Pad 46, 46-20 and 46CC

Technical Data

July 2012

Description:

The Scotch-Brite™ Griddle Polishing Pad 46, 46-20 and 46CC is a heavy duty open construction scouring pad made from synthetic fibers, minerals, and resin. It is designed to be used for cleaning flat top griddles.

The pad is an integral part of the 461 Griddle Cleaning System.

Special Features:

- Tough, non-rusting and resilient high quality synthetic fibers to provide long lasting usage.
- Abrasive minerals selected to provide remarkable scouring for griddle cleaning.
- Abrasive mineral particles evenly distributed throughout the pad to help ensure effective, consistent, and long lasting performance throughout the life of the pad.
- High quality bonding resin system designed to provide resistance to degradation from exposure to hot water, detergents and normal cleaning liquids.
- Aggressive, heavy duty and open pad construction to provide fast cleaning and multiple uses, resist clogging, and rinse clean easily.
- Heat resistant pad to allow for cleaning griddle at operating temperature throughout the day.

Applications:

Test in an inconspicuous area prior to use.

Use for cleaning, scouring, and polishing griddle surface.

Packaging:

46: 20 Pads/Box, 3 Boxes/Case
46-20: 20 Pads/Case
46CC: 10 Pads/Pack, 6 Packs/Case

General Use Directions:

The pad can be used wet or dry on griddles at operating temperature up to 350°F.

For use with the 461 Griddle Cleaning System, the pad is sandwiched between a Scotch-Brite™ Griddle Pad Holder 461 and a Scotch-Brite™ Griddle Screen 200.

1. Place a griddle screen on griddle surface, pad on top of the screen, and then the griddle pad holder on top of the pad. Apply desired pressure evenly and scrub griddle surface in circular motion.
2. Wipe off griddle surface with clean, damp cloth.
3. Clean pad as necessary after use.

Pad Cleaning Instructions:

Cleaning pad provides multiple uses. Used and/or worn-out pad can be disposed of in regular kitchen trash.

Pads can be rinsed with warm or hot water or soaked in a cleaning solution to dissolve caked-on soil and grease.

Pad Cleaning by Hand

1. Spray or rinse excess food debris from pad using a dish sprayer or sink faucet.

2. Wash the pad in soapy water to remove any remaining food debris and grease. Remove imbedded food debris from the pad by hand.
3. Rinse pad with clean water. Make sure no food debris is left on the pad. Shake excess water from the pad and allow to air dry.

If desired, soak pad in sanitizer solution. After soaking, shake excess solution from the pad, rinse and allow to air dry.

Pad Cleaning by Dishwasher

1. Spray or rinse excess food debris from pad using a dish sprayer or sink faucet.
2. Place the pad in dishwasher and make sure both sides of the pad are exposed to washing.
3. After washing, take pad out of dishwasher and allow to air dry.

Product Specifications:

(Typical Values)

1. Size:
 - Pad length: 5.25 inches
 - Pad width: 4.0 inches
 - Pad thickness: 0.6 inch
2. Color: Gray

Precautionary Summary:

- Do not use on polished or easily scratched surfaces.



3M Branch Sales Offices

ANCHORAGE

11151 Calaska Circle
Anchorage, AK 99515
Telephone: 907/522-5200
Facsimile: 907/522-1645

HONOLULU

4443 Malaai Street
Honolulu, HI 96818
Mail to: P.O. Box 30048
Honolulu, HI 96820
Telephone: 808/422-2721
Facsimile: 808/422-9557

CONTINENTAL UNITED STATES

Customer Service Department
3M Center Building 223-2N-20
St. Paul, MN 55144-1000
Order Entry: 800/698-4595
Facsimile: 877/318-0220

CANADA

1840 Oxford Street East
London, Ontario, Canada
N5V 3G2
Mail to: P.O. Box 5757
London, Ontario, Canada
N6A 4T1
Telephone: 800/364-3577
Facsimile: 800/479-4453

Important Notice to User:

Technical Information: The technical information, recommendations and other statements contained in this document are based upon tests or experience that 3M believes are reliable, but the accuracy or completeness of such information is not guaranteed.

Product Use: Many factors beyond 3M's control and uniquely within user's knowledge and control can affect the use and performance of a 3M product in a particular application. Given the variety of factors that can affect the use and performance of a 3M product, user is solely responsible for evaluating the 3M product and determining whether it is fit for a particular purpose and suitable for user's method of application.

Warranty and Limited Remedy: 3M warrants that each 3M product will be free from defects in material and manufacture for 90 days from the date of purchase from 3M's authorized distributor. 3M MAKES NO OTHER EXPRESS OR IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. If a 3M product does not conform to this warranty, the sole and exclusive remedy is, at 3M's option, replacement of the 3M product or refund of the purchase price.

Limitation of Liability: Except where prohibited by law, 3M will not be liable for any loss or damage arising from the 3M product, whether direct, indirect, special, incidental or consequential, regardless of the legal theory asserted.



Building and Commercial Services Division

St. Paul, MN 55144-1000
www.3M.com/foodservice

3M and Scotch-Brite are trademarks of 3M Company. Used under license in Canada.
©3M 2012. All rights reserved
DMR 805406