

Parts Catalog



Model GPGDUE10

BISTRO SERIES ELECTRIC SANDWICH GRILLS

MODELS: GPG10, GSG10, GPGDUE10, GSGDUE10

CANADIAN MODELS: GPG10-C, GSG10-C, GPGDUE10-C, GSGDUE10-C

1-19-15

IMPORTANT!

TO EXPEDITE SHIPMENT OF PARTS, ALWAYS SPECIFY MODEL, REV,
PART NUMBER, AND SERIAL NUMBER OF UNIT.

GLOBE FOOD EQUIPMENT COMPANY

2215 East River Road
Dayton, Ohio 45439

Parts Department

Toll Free 1-800-745-6238 · Fax (937) 290-0585

E-Mail: info@globefoodequip.com


Website: www.globefoodequip.com

Not for resale

TABLE OF CONTENTS

	<u>PAGE</u>
GPG10/GSG10/GPG10-C/GSG10-C Single Grill	1-2
GPGDUE10/GSGDUE10/GPGDUE10-C/GSGDUE10-C Double Grill	3-4
Wiring Diagram, GPG10/GSG10	5
Wiring Diagram, GPGDUE10/GSGDUE10	6


GPG10/GSG10/GPG10-C/GSG10-C 10 INCH SINGLE GRILL COMPONENTS



GPG10/GSG10/GPG10-C/GSG10-C 10 INCH SINGLE GRILL PARTS LIST

ITEM	DESCRIPTION	PART NUMBER	QTY	HARDWARE
1	Top Cover	U00707	1	
2	Upper Insulating Plate	U00708	1	
3	Upper Mica Plate	U00709	1	
4	Upper Element	U03061225050	1	
5	Adjustable Tension Bracket	U00710	1	
6	Handle	U00712	1	
7	Upper Cast Iron - Sandwich Grill (Smooth)	U00711	1	
	Upper Cast Iron - Panini Grill (Grooved)	U00713		
8	Back Baffle	U00714	1	
9	Wiring Cover	U01021005045	1	
10	Lower Cast Iron - Sandwich Grill (Smooth)	U00715	1	
	Lower Cast Iron - Panini Grill (Grooved)	U00716		
11	Lower Element	U03061225051	1	
12	Lower Mica Plate	U00717	1	
13	Lower Insulating Plate	U00718	1	
14	Body Assembly	U00719	1	
15	Cord & Plug	U03021205012	1	
	Cord & Plug (Models GPG10-C/GSG10-C Only)	U03021205010		
16	Foot	U02121165004	4	
17	Base Plate	U01071040021	1	
18	Power Switch	U03041215027	1	
19	Indicator Light	U03091240005	1	
20	Thermostat	U03051220022	1	
21	Dial	U02101155019	1	
22	Drip Tray	U01051026865	1	


GPGDUE10/GSGDUE10/GPGDUE10-C/GSGDUE10-C 10 INCH DOUBLE GRILL COMPONENTS




GPGDUE10/GSGDUE10/GPGDUE10-C/GSGDUE10-C 10 INCH DOUBLE GRILL COMPONENTS

ITEM	DESCRIPTION	PART NUMBER	QTY	HARDWARE
1	Top Cover	U00720	2	
2	Upper Insulating Plate	U00733	2	
3	Upper Element Insulating Plate	U00721	2	
4	Adjustable Tension Bracket	U01021005138	2	
5	Upper Element	U03061225060	2	
6	Handle Assembly, Left	U00722	1	
7	Handle Assembly, Right	U00723	1	
8	10" Upper Right Cast Iron - Panini Grill (Grooved)	U00724	1	
	10" Upper Left Cast Iron - Panini Grill (Grooved)	U00725		
	10" Upper Right Cast Iron - Sandwich Grill (Smooth)	U00726		
	10" Upper Left Cast Iron - Sandwich Grill (Smooth)	U00727		
9	Back Plate, Right	U00728	1	
10	Back Plate, Left	U00729	1	
11	Wiring Cover, Right	U01021005045	1	
12	Wiring Cover, Left	U00701	1	
13	20" Lower Cast Iron - Sandwich Grill (Smooth)	U00730	1	
	20" Lower Cast Iron - Panini Grill (Grooved)	U00731		
14	Body Assembly	U00732	1	
15	Cord & Plug	U03021205011	1	
	Cord & Plug (Models GPGDUE10-C/GSGDUE10-C Only)	U03021205010		
16	Lower Element	U03061225061	2	
17	Lower Mica Plate	U00721	2	
18	Lower Insulating Plate	U00733	2	
19	Base Plate	U01071040231	1	
20	Foot	U02121165004	4	
21	Power Switch	U03041215027	2	
22	Indicator Light	U03091240006	2	
23	Thermostat	U03051220022	2	
24	Dial	U02101155019	1	
25	Drip Tray	U01051027353	1	

WIRING DIAGRAM, 10 INCH SINGLE GRILL: GPG10/GSG10



WIRING DIAGRAM, 10" DOUBLE GRILL: GPGDUE10/GSGDUE10



NOTES

