

SPARE PARTS - LETTUCE KING I

LETTER	PART NUMBER	DESCRIPTION
A	060	RUBBER FOOT (OLD STYLE)
	303	RUBBER FOOT, DEEP (NEW STYLE)
B	0655	RUBBER SEAL
C	414	SCREW FIL. HD., 1/4-20 X 3/4"
D	415	SCREW, HEX HD., 1/4-20 X 7/8"
E	420	BLADE BLOCK
F	424	BLADE BLOCK PIN
G	426	LEG CASTING, FRONT / REAR
H	427	BLADE BLOCK SCREW, 1/4-20 X 2"
I	4422R	SCREW, SQ. HD., 1/4-20 X 3/8"
J	452	PUSHER HEAD 3/4" - INCLUDES: 20 SPACERS, 11 FINGERS, 2 RETAINING RODS, 4 NUTS
	482	PUSHER HEAD 3/8" - INCLUDES: 38 SPACERS, 20 FINGERS, 2 RETAINING RODS, 4 NUTS
	483	PUSHER HEAD 1/4" - INCLUDES: 56 SPACERS, 29 FINGERS, 2 RETAINING RODS, 4 NUTS
K	453	PUSHER HEAD LOCKING COLLAR - INCLDS. COLLAR & SCREW
L	454	PUSHER HEAD PIVOT ROD
M	455	PUSHER HEAD HANDLE - INCLDS. HANDLE ROD & 2 PLASTIC GRIPS
N	456	PUSHER HEAD SIDE ARM - RIGHT HAND
O	457	PUSHER HEAD SIDE ARM - LEFT HAND
P	468	BASE CASTING
Q	490	NYLON WASHER
R	506	PUSHER HEAD BUMPER
S	519	ACORN NUT, 1/4"
T	485	BLADE ASSY 1/4" - INCLUDES: 28 BLADES, 2 BLOCKS, 2 PINS, 2 SHIELDS
	484	BLADE ASSY 3/8" - INCLUDES: 19 BLADES, 2 BLOCKS, 2 PINS, 2 SHIELDS
	434	BLADE ASSY 3/4" - INCLUDES: 10 BLADES, 2 BLOCKS, 2 PINS, 2 SHIELDS
U	--	BLADE SHIELD - PART OF BLADE ASSEMBLY
NOT SHOWN	4425	LETTUCE CUTTER BRUSH

EXPLODED VIEW PARTS DIAGRAM - LETTUCE KING I

