

Double Adjustable Heat Lamp with Metal Base

Instruction & Specification Sheet

HL029 – Double Adjustable Height Heat Lamp, Black Matte

HL030 – Double Adjustable Height Heat Lamp, Stainless Steel

BEFORE YOU BEGIN

1. Please read instructions before using this appliance. This appliance is not intended for household use.
2. When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury.
3. Clean appliance thoroughly before and after each use following the cleaning instructions on back.

SAFETY INFORMATION

1. Never leave the unit unattended when operating.
2. This heat lamp is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Keep combustible materials, such as drapes and other furnishings away from unit.
3. To prevent a possible fire, it is recommended that the unit is placed on a non-combustible surface.
4. Close supervision is necessary when the unit is used near children.
5. Always unplug appliance when not in use and before cleaning, adjusting or maintaining this unit. To disconnect unit, turn power switch off and remove plug from outlet.
6. Do not operate unit with a damaged cord, plug, or light socket.
7. Do not use outdoors. This appliance is not intended for wet or moist locations. Never place unit where it may fall into water.
8. Connect to properly grounded outlets only. Avoid the use of extension cords. Do not run the power cord under carpeting, runners or the like. Arrange cord away from high traffic areas, where it will not create a tripping hazard.
9. Do not carry the lamp by gripping the metal arms. Always carry lamp by the base.
10. To protect against electrical shock, do not immerse the unit, cord, or plug in water or other liquid.
11. This appliance has electrical parts. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.

OPERATION

1. Carefully remove product from packaging. Make sure to remove packing material from inside and around lamp shade.
2. Place heat lamp on a stable, level surface. Always carry lamp by base and never metal arms.


3. Take provided light bulb and screw into light socket in lamp shade.
4. Plug power cord into a grounded outlet. Always maintain a distance of at least 12" between the lamp shade and any wall.
5. Turn lamp on by flipping ON/OFF switch on base.
6. If lamp fails to work properly when first operated contact Rosseto customer service.
7. Place food directly under the bulb for best results.
8. The adjustable height allows lamp be repositioned.
9. When in use, lamp shade becomes hot. Use caution to not touch with bare skin.
10. Turn heat lamp off when not in use.
11. To disconnect heat lamp, turn switch off and remove plug from power source.
12. Allow unit to cool completely before cleaning or storing.
13. If light bulb needs to be changed, always unplug the unit and allow to cool completely before changing bulb.

Shade Operation

The flexible stem allows the shade to be lowered and raised. Pull down on the shade to lower position. To return the shade to the original position, pull down slightly on the shade and the shade will retract to the original position.

Connecting Lamps Together


The receptacle on back of the base must only be used to connect additional lamps. **PLUGGING IN**



ANY OTHER DEVICE COULD RESULT IN A SHORT CIRCUIT OR FIRE. The diagrams below show how many lamps can be connected depending on the wattage of the bulbs used.


WARNING!

When using **250W** bulbs, **NEVER** connect more than **2** Heat Lamps together at any time.



WARNING!

NEVER connect additional Heat Lamps when using **300W** bulbs.




NEED ASSISTANCE?

Customer Service Support: **847-763-1215**

Address: **3714 Jarvis Avenue Skokie, IL 60076**

Website: **www.rosseto.com**



Double Adjustable Heat Lamp with Metal Base

Instruction & Specification Sheet

HL029 – Double Adjustable Height Heat Lamp, Black Matte

HL030 – Double Adjustable Height Heat Lamp, Stainless Steel

TECHNICAL DATA

Item #	Base Description	Voltage	Hertz	Max Watts	Amps	Plug Type
HL029	Single Black Matte	110V–250V	50Hz–60hz	300	5	US NEMA 5-15P
HL030	Single Stainless Steel	110V–250V	50Hz–60hz	300	5	US NEMA 5-15P
HLB001	Light Bulb (Incandescent & Shatterproof): Voltage: 110V, Wattage: 250W, Bulb Type: R/BR40, Screw type: E27					
HLB002	Light Bulb (Incandescent & Shatterproof): Voltage: 110V, Wattage: 300W, Bulb Type: R/BR40, Screw type: E27					

SPECIFICATIONS

Product dimensions:

L x W x H – 18.31 x 11.22 x 37.4 IN

L x W x H – 46.5 x 28.5 x 95 CM


Length of adjustable flexible stem:

4.72 to 11.8 IN

12 to 30 CM

Product Weight:

39 lb / 17.70 kg



CARE AND CLEANING

1. Turn heat lamp off and unplug the cord before cleaning.
2. After unit has cooled, wipe down base, arms, and shade with a warm, damp cloth and mild soap solution.
3. Do not immerse in water or other liquid as electrical components will be destroyed.

DO NOT put any part of the unit through dishwasher or dryer machine or soak in water.

DO NOT use any abrasive materials such as scrubbing pads, scrapers, or metal-based brushes.

NEED ASSISTANCE?

Customer Service Support: **847-763-1215**

Address: **3714 Jarvis Avenue Skokie, IL 60076**

Website: **www.rosseto.com**

