





Electrical Diagram-SP30 PLANETARY MIXER 115V Single Phase



ITEM	DESCRIPTION	QTY
S1	EMERGENCY STOP BUTTON	1
S2	START BUTTON	1
S3	MICROSWITCH (BOWL LIFT)	1
S4	MICROSWITCH (INTERLOCK GUARD)	1
K1	CONTACTOR	1
K2	TIMER	1
M1	MOTOR, 1HP SINGLE PHASE 115V	1



Electrical Diagram-SP30 PLANETARY MIXER 220V Single Phase




ITEM	DESCRIPTION	QTY
S1	EMERGENCY STOP BUTTON	1
S2	START BUTTON	1
S3	MICROSWITCH (BOWL LIFT)	1
S4	MICROSWITCH (INTERLOCK GUARD)	1
K1	CONTACTOR	1
K2	TIMER	1
M1	MOTOR, 1.5HP SINGLE PHASE 220V	1



SP30 115V

SINGLE PHASE TYPE





SP30P 220V SINGLE PHASE TYPE

