





Electrical Diagram-SP60 PLANETARY MIXER 220V Single Phase



ITEM	DESCRIPTION	QTY
S1	EMERGENCY STOP BUTTON	1
S2	START BUTTON	1
S3	MICROSWITCH (BOWL LIFT)	1
S4	MICROSWITCH (INTERLOCK GUARD)	1
K1	CONTACTOR	1
K2	TIMER	1
M1	MOTOR, 3HP SINGLE PHASE 220V	1



Electrical Diagram-SP60 PLANETARY MIXER 208V Three Phase




ITEM	DESCRIPTION	QTY
S1	EMERGENCY STOP BUTTON	1
S2	START BUTTON	1
S3	MICROSWITCH (BOWL LIFT)	1
S4	MICROSWITCH (INTERLOCK GUARD)	1
K1	CONTACTOR	1
K2	TIMER	1
M1	MOTOR, 3HP THREE PHASE 208V	1



SP60

SINGLE PHASE TYPE





SP60

THREE PHASE TYPE

