# CARE AND MAINTENANCE FOR ALL CAMBAR MODELS

Congratulations on the purchase of your new Cambro Cambar! Although the bar is designed to be weather - proof, please avoid exposing the bar to direct sunlight for prolonged periods of time and avoid placing it in situations where it can absorb the high intensity sunlight reflected from glass or other mirrored surfaces. Avoid situations where temperatures may exceed 200°F as this may cause damage to your bar.

## **CLEANING INSTRUCTIONS**

For all body parts such as the main body section, front body panel section, speed rail, waste water bin and fresh water tank:

- Clean with a soft cloth, plastic or bristle brush and warm soapy water or a mild commercial detergent. Sanitizing solutions are also recommended.
- Rinse thoroughly with clean water. If staining occurs use a standard de-stainer such as Dip It® Cleaner.
- All parts can also be steam cleaned.

## WARNING! Never use a metal brush, abrasive cleaners or pads.

## To remove any lingering scents and stains:

Use an odor removing soak or sanitizer to remove scents and stains that can occur from holding products with strong odors.

- A diluted solution of 2-3 tablespoons of baking soda per gallon of hot tap water or 1 part lemon juice or vinegar to 4 parts hot water is also an effective way to remove lingering odors.
- Rinse thoroughly with hot water and let air dry or wipe down with a soft cloth.

# To maintain a shiny finish to the granite style counter tops of the designer series:

It is recommended to use Gel-Gloss<sup>®</sup> cleaner and polish, following the instructions on the back of the container.







www.cambro.com

## CLEANING INSTRUCTIONS (continued)

To clean the decorative front and side panels of the designer series:




The following products have been found to be compatible:

- Isopropyl alcohol
- Joy<sup>®</sup> Dishwashing Liquid
- Mr. Clean®
- Palmolive®
- Windex<sup>®</sup> Ammonia-D

## **CASTER MAINTENANCE**

### To be performed after unit has been washed or steam cleaned:

- 1. Grease swivel raceway of caster using a lubricant such as Lubriplate No. 930-AA, Keystone #84EPXLT multi-purpose grease or the equivalent. Moving "O" Ring or seal with finger, apply grease using a grease gun with a needle nose adapter or a tube-type applicator such as "Sta-lube" Moly-graph Assembly Lube (Fig. 1). These can be obtained at most auto parts stores.
- 2. Use a light oil such as WD-40 on the nylon bushing at the hub (Fig. 2).
- 3. Check caster for any damage and test caster spin and swivel rotation before returning to service.









 Telephone
 714 848 1555
 Toll Free 800 854 7631
 Customer Service 800 833 3003

 © Cambro Manufacturing Company 5801 Skylab Road, Huntington Beach, California 92647-2056
 Printed in USA 3/16

### INSCAMBAR